


XC-152 Compact PLC



Powering Business Worldwide

Impressum

Manufacturer

Eaton Automation AG
Spinnereistrasse 8-14
CH-9008 St. Gallen
Switzerland
www.eaton.eu

Support

Region North America

Eaton Corporation
Electrical Sector
1111 Superior Ave.
Cleveland, OH 44114
United States
877-ETN-CARE (877-386-2273)
www.eaton.com

Other regions

Please contact your local supplier or send an Email
to: automation@eaton.com

Original instructions

The German version of this document is the original instructions.

Translations of the original instructions

All non-German editions of this document are translations of the original instructions.

Editor

Monika Jahn

Brand and product names

All brand and product names are trademarks or registered trademarks of the owner concerned.

Copyright

© Eaton Automation AG, CH-9008 St. Gallen

All rights reserved, also for the translation.

None of this document may be reproduced or processed, duplicated or distributed by electronic systems in any form (print, photocopy, microfilm or any other process) without the written permission of Eaton Automation AG, St. Gallen.

Subject to modifications.

Contents

1	General	5
1.1	Purpose of these Operating Instructions.....	5
1.2	Comments about this document.....	5
1.3	Additional documentation.....	6
2	Device description	7
2.1	Function.....	7
2.2	Intended use.....	7
2.3	Device versions.....	7
2.4	Package contents.....	8
2.5	Accessories.....	8
2.6	Designation.....	8
3	Safety regulations	9
3.1	General.....	9
3.2	Meaning of symbols.....	10
3.3	Mandatory requirements, personnel.....	11
3.3.1	Work safety.....	11
3.3.2	Qualification of personnel.....	11
3.3.3	Operating Instructions.....	11
3.3.4	Installation, maintenance and disposal.....	11
3.3.5	Prohibited use.....	11
3.3.6	Requirements for proper operation.....	12
3.4	Device related hazards.....	13
4	Operating and indication elements	15
4.1	Operating and indication elements on the front.....	15
4.2	Operating elements on the service side.....	16
5	Installation	17
5.1	Safety regulations.....	17
5.2	Requirements for the place of installation.....	18
5.2.1	Engineering conditions of acceptability by Underwriters Laboratories Inc. (UL).....	18
5.2.2	Requirements for the mounting position.....	18
5.3	Interfaces.....	19
5.3.1	Overview of interfaces.....	20
5.3.2	Preparation of cables with D-Sub connector.....	21
5.3.3	Power supply.....	23
5.3.4	RS232 (System Port).....	24
5.3.5	Ethernet.....	26
5.3.6	USB Device.....	27
5.3.7	USB Host.....	27
5.3.8	SmartWire-DT Master.....	28
5.3.8.1	Additional documentation for devices with SmartWire-DT Master interface.....	28
5.3.8.2	Operating and indication elements of the SmartWire-DT Master interface.....	29
5.3.8.3	POW/AUX (power supply for SmartWire-DT).....	30

Contents


5.3.8.4	SWD (SmartWire-DT interface).....	31
5.3.8.5	Commissioning of the SmartWire-DT network	32
5.3.9	CAN.....	34
5.3.10	Profibus	37
5.3.11	RS485	39
5.4	Mounting the device	41
5.4.1	Mounting and removing the device on a top-hat rail	42
5.4.2	Mounting the device with fixing brackets (screw mounting)	43
6	Operation	45
6.1	Safety regulations	45
6.2	Starting the device	45
6.3	Switching off the device	45
6.4	Inserting and removing an SD card.....	46
7	Maintenance and service.....	47
7.1	Safety regulations	47
7.2	Maintenance.....	47
7.2.1	Battery.....	47
7.3	Service	47
7.3.1	Repairs.....	47
7.4	Troubleshooting	48
8	Storage, transport and disposal	49
8.1	Safety regulations	49
8.2	Storage.....	49
8.3	Transport.....	49
8.4	Disposal	50
9	Technical data	51
9.1	Dimensions and weights	51
9.2	System	52
9.3	Interfaces	52
9.3.1	Power supply.....	53
9.3.2	SmartWire-DT Master	54
9.3.2.1	POW/AUX (power supply interface for SmartWire-DT).....	54
9.3.2.2	SWD (SmartWire-DT interface).....	55
9.4	Enclosure ratings	56
9.5	Agency approvals and standards.....	56
9.6	Applicable standards and regulations	56
9.7	Ambient conditions.....	57

1 General

1.1 Purpose of these Operating Instructions

These Operating Instructions contain the information required for the correct and safe use of the compact PLCs XC-152. The Operating Instructions are part of the devices and must therefore be kept nearby.

These Operating Instructions describe all aspects of the devices: transport, installation, commissioning, operation, maintenance, storage and disposal. The operating system and the application software are not described.

 **Read Chapter 3 Safety regulations, 9 before working with the device. This contains important information for your personal safety. This chapter must be read and understood by all persons working with this device.**

WARNING



Incomplete copy of the Operating Instructions

Working with individual pages of these Operating Instructions may cause damage to property or personnel by failure to observe safety-related information.

▶ Always work with the complete document.

1.2 Comments about this document

Please send any comments, recommendations or suggestions relating to this document to info-automation@eaton.com.

1 General

1.3 Additional documentation

1.3

Additional documentation

The following documents may be helpful in the use of the device in addition to this document. These can be downloaded from www.moeller.net, «Support» section and from www.eaton.eu (search document No. via search field of the home page).

- [1] MN05010007Z-EN System Description Windows CE
(operation of the Windows CE operating system on MICRO PANELs)
- [2] MN05010009Z-EN System Description Networks in Brief
(information on networks in general and on the integration of PCs and MICRO PANELs in networks)
- [3] MN05003007Z-EN User Manual XSoft-CoDeSys-2: PLC Programming XC-152
(use of the PLC programming tool XSoft-CoDeSys-2 and the PLC runtime system for the XC-152 device type with Windows CE)



Documents relevant for the devices with SmartWire-DT Master interface, see Chapter 5.3.8 SmartWire-DT Master, 28.

2 Device description

2.1 Function

The compact PLCs XC-152 are controllers with a large number of different interfaces for communication.

2.2 Intended use

The compact PLCs XC-152 are primarily used in machine and system building. They are designed exclusively for the control of machines and systems. Any other use must be agreed beforehand with the manufacturer.

2.3 Device versions



Fig. 1 XC-152

The compact PLCs XC-152 are available in the following versions:

Basic device	Communication interfaces	XC-152 type
■ 1 Slot for 1 SD card	CAN, RS485 and RS232	XC-152-D6-11
■ Integrated interfaces: 1 × Ethernet 100/10	Profibus, RS485 and RS232	XC-152-D8-11
1 × USB Device	SmartWire-DT Master and RS232	XC-152-E3-11
1 × USB Host	SmartWire-DT Master, CAN and RS485	XC-152-E6-11
Communication interfaces	SmartWire-DT Master, Profibus and RS485	XC-152-E8-11

Tab. 1 Device versions

2 Device description

2.4 Package contents

2.4

Package contents

The package contents of the compact PLCs XC-152 consist of the following:

Qty	Designation
1	Compact PLC: ■ XC-152-...
1	Power supply connector for the device
1	Power supply connector for SmartWire-DT Master (only supplied with XC-152-E... devices)

Tab. 2 Package contents

2.5

Accessories

Different accessories are available. Use only original accessories.



Order the accessories required from your supplier.

2.6

Designation

Front of the device

The front of the device contains the following information:

- Manufacturer's name
- Type designation
- Part no.
- Version
- MAC address
- Serial no.
- Time of manufacturing (week/year)
- Power supply required
- Approval mark and information to the approval
- Arrangement of interfaces and operating elements

Support

To ensure fast and optimum support always provide the support personnel with the following information on the nameplate:

- Part no.
- Serial no.

3 Safety regulations

3.1 General

Hazards may still occur even though the device meets the current state of the art and complies with all recognized safety requirements.

The device must only be installed and commissioned in perfect technical condition and in compliance with this document.



Read this chapter before working with the device. This contains important information for your personal safety. This chapter must be read and understood by all persons working with this device.





3 Safety regulations

3.2 Meaning of symbols

3.2

Meaning of symbols

The following symbols are used in this document according to the hazard level described:

⚠ DANGER	
	<p>Signal word DANGER</p> <p>Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.</p>
⚠ WARNING	
	<p>Signal word WARNING</p> <p>Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.</p>
⚠ CAUTION	
	<p>Signal word CAUTION</p> <p>Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.</p>
CAUTION	
	<p>Signal word CAUTION without safety alert symbol</p> <p>Indicates a situation which, if not avoided, could result in material damage.</p>

 **Indicates useful information.**

The danger symbol used and the text indicate the actual danger and the related preventative measures.

3 Safety regulations

3.3 Mandatory requirements, personnel

3.3 Mandatory requirements, personnel

3.3.1 Work safety



All applicable work safety regulations (in-house and national) must be observed.

3.3.2 Qualification of personnel

The personnel responsible for installation, operation, maintenance and service must be adequately qualified. These persons must be sufficiently trained or instructed and they must be informed of all hazards and risks associated with the device.

3.3.3 Operating Instructions

It must be ensured that any person working with the device in any phase of its lifespan has read and understood the relevant sections of the Operating Instructions.

 WARNING	
	<p>Incomplete copy of the Operating Instructions</p> <p>Working with individual pages of these Operating Instructions may cause damage to property or personnel by failure to observe safety-related information.</p> <p>▶ Always work with the complete document.</p>

3.3.4 Installation, maintenance and disposal

It must be ensured that the device is properly connected, mounted, maintained and disposed of in compliance with all relevant standards and safety regulations.

3.3.5 Prohibited use

The implementation of safety functions (relating to the protection of personnel and machinery) using the device is prohibited.

3 Safety regulations

3.3 Mandatory requirements, personnel

3.3.6

Requirements for proper operation

The following points must be observed so that the device meets the contractual requirements:

- Only qualified personnel may work with the device.
- These persons must have read the Operating Instructions and must observe the requirements described.
- The ambient conditions stated must be observed. See Chapter 9.7 Ambient conditions, 57.
- The maintenance work must be carried out correctly.

No liability is accepted for damage, consequential damage and accidents caused by the following:

- Failure to observe work safety regulations
- Failure or malfunction of the device
- Improper handling or use
- Failure to observe the Operating Instructions
- Conversions, modifications and repairs to the device



Repairs, see Chapter 7.3.1 Repairs, 47.

3.4

Device related hazards

⚠ DANGER**Explosion hazard**

Death, serious injury or material damage may occur if the device is used in potentially explosive atmospheres.

- ▶ Only use the device in environments not subject to explosion hazards.

⚠ WARNING**Live parts in the device**

When the device is opened, there is a risk of electric shock if live parts are touched.

- ▶ The device must not be opened.

⚠ WARNING**Potential equalization currents**

Large equalization currents between the protective ground systems of different devices may cause operational malfunctions due to signal interference and may even cause fires.

- ▶ If necessary, a potential equalization conductor should be installed parallel to the cable. This should have a cross-section that is a multiple of the cable shield.

⚠ CAUTION**Electrostatic discharge**

Electrostatic discharge may damage or destroy electronic components.

- ▶ Avoid contact with components (such as connector pins) that are susceptible to electrostatic discharge.
- ▶ Discharge (by touching a grounded metal object) any static charge accumulated in your body before touching the device.

CAUTION**Non-isolated interfaces**

The device may be damaged due to potential differences.

- ▶ The GND terminals of all bus stations must be connected.

3 Safety regulations

3.4 Device related hazards

CAUTION



Data loss

During a write operation, the SD card may lose data or may be destroyed if it is removed or if there is a power failure.

- ▶ Only insert the SD card when the device is in a de-energized state.
- ▶ Avoid write operations to SD cards. Reasons:
 - The number of write cycles possible on SD cards is limited.
 - A power failure during write operations will most likely lead to loss of data.
- ▶ Only remove the SD card when the device is in a de-energized state.
- ▶ Before switching off, ensure that no software write operations to the SD card are in progress.

CAUTION



Device condensation

If the device is or was exposed to climatic changes (temperature fluctuation, air humidity) moisture can form on or in the device (device condensation). In this case, there is a risk of short-circuit.

- ▶ The device must **not** be switched on when device condensation is present.
- ▶ If condensation is present on the device, or if it was exposed to temperature fluctuations, it must be allowed to adjust to room temperature (do not expose the device to the direct heat of heating devices) prior to commissioning.

CAUTION



UV light

When exposed to UV light, plastics can embrittle and the lifespan of the device is reduced.

- ▶ Protect the device against direct sunlight (UV rays).

CAUTION



Cleaning the device

Damage to the device due to the use of pointed or sharp objects or by liquids.

- ▶ Do not use any pointed or sharp objects (e.g. knife) for cleaning.
- ▶ Do not use any aggressive or abrasive cleaning agent or solvent.
- ▶ Avoid any liquid entering the device (risk of short-circuit).

4 Operating and indication elements

4.1 Operating and indication elements on the front

4 Operating and indication elements

4.1 Operating and indication elements on the front




Fig. 2 Operating and indication elements on the front

The device has the following operating and indication elements on the front:

Element	Function
A RUN/STOP switch	Switch between the following operating modes of the PLC program: <ul style="list-style-type: none"> ■ RUN (warm start): When starting the PLC program, the retentive (RETAIN, RETAIN PERSISTENT) tags of the PLC program keep their current values. If the PLC program is started the first time, a cold start is initiated even if warm start is set. ■ STOP (cold start): When starting the PLC program, all tags of the PLC program are initialized with their initialisation values before starting.
B RUN/STOP LED	<ul style="list-style-type: none"> ■ Lit if the device is supplied with current. ■ Indicates whether the PLC program is running, → Chapter 7.4, 48.
C SF LED	This LED indicates different states of the device and of the software, → Chapter 7.4, 48.
D COM LED	<ul style="list-style-type: none"> ■ Lit green if data is transferred via the CAN or Profibus interface. ■ Other states of this LED, → Chapter 7.4, 48.

Tab. 3 Operating and indication elements on the front

4 Operating and indication elements

4.2 Operating elements on the service side

4.2

Operating elements on the service side




Fig. 3 Operating elements on the service side

The device has the following operating elements on the service side:

Element	Function
A SD slot	Slot for SD card.
B CTRL button	<ul style="list-style-type: none"> ■ Force starting the device by DHCP function: If the CTRL button is pressed while switching on the device (until the SF LED is solid green), then the device applies an IP address from DHCP. When thereafter the CTRL button is hold down for 5 seconds (until the SF LED flashes green), then the IP address 192.168.1.1 is temporarily assigned to the device. In this mode, the files Auto-exec.bat, Autoexec.reg and Autoexec.bmp are not executed. ■ If the operating system is invalid or does not exist on the SD card (COM LED flashes red or orange), the internal operating system can be started by pressing the button.

Tab. 4 Operating elements on the service side

5 Installation

5.1 Safety regulations



Read Chapter 3 Safety regulations, 9 before installing and commissioning the device. This contains important information for your personal safety.

5 Installation

5.2 Requirements for the place of installation

5.2

Requirements for the place of installation

- Approvals:
The device must only be used in locations that are approved for the device. See the markings on the nameplate and Chapter 9 Technical data, 51.
- Power supply:
The power supply must comply with the requirements stated in Chapter 9.3.1 Power supply, 53.

5.2.1

Engineering conditions of acceptability by Underwriters Laboratories Inc. (UL)

For the approval in accordance with the standard UL 508, consideration must be given to the following:

- Ambient conditions:
 - Max. ambient temperature: 55°C
 - Pollution degree 2
- The screw terminals of the connector for the power supply must be tightened with a max. tightening torque of 0.6...0.8 Nm or 5...7 Lb. In.
- Only devices with SmartWire-DT Master interface (XC-152-E...):
The supply voltage U_{AUX} of the SmartWire-DT Master interface must be protected externally against over-current and short-circuit by:
 - miniature circuit-breaker 24 VDC, rated current 2 A, tripping characteristic Z
 - or fuse 2 A.

5.2.2

Requirements for the mounting position

The device is designed for mounting in control cabinets, control panels or control desks. It can be mounted horizontally or vertically. The following requirements must be fulfilled when selecting a suitable mounting position:

- The device should not be exposed to direct sunlight (when exposed to UV light, plastic parts of the device can embrittle and the lifespan of the device is reduced).
- The operating elements on the service side of the device and the cable connections are accessible after the device has been mounted.
- The ambient conditions stated must be observed. See Chapter 9.7 Ambient conditions, 57.
- Sufficient ventilation (cooling) must be ensured by means of:
 - Clearance of at least 3 cm to the ventilation slots
 - Clearance of at least 15 cm from heat radiating components such as heavily loaded transformers
 - The expected temperatures should be within the permissible range. See Chapter 9.7 Ambient conditions, 57.

5.3

Interfaces

⚠ WARNING**Potential equalization currents**

Large equalization currents between the protective ground systems of different devices may cause operational malfunctions due to signal interference and may even cause fires.

- ▶ If necessary, a potential equalization conductor should be installed parallel to the cable. This should have a cross-section that is a multiple of the cable shield.

⚠ CAUTION**Operational malfunctions**

Use of unsuitable or improperly prepared cables, as well as incorrect wiring will mean that neither the values stated in the technical data nor the electromagnetic compatibility (EMC) can be ensured.

- ▶ Only use cables prepared by specialists.
- ▶ The cables used must be prepared according to the interface description in this document.
- ▶ The wiring instructions for the relevant interface must be observed when wiring the device.
- ▶ Any generally applicable regulations and standards must be fulfilled.

⚠ CAUTION**Non-isolated interfaces**

The device may be damaged due to potential differences.



- ▶ The GND terminals of all bus stations must be connected.

5 Installation

5.3 Interfaces

5.3.1

Overview of interfaces

 The interfaces will vary depending upon the device version. See nameplate and Chapter 2.3 Device versions,  7.













Fig. 4 Interfaces of the device

Interface	Interface description
A Jumper UPD/RUN	Only for service tasks
B DIAG	Only for service tasks
C USB Device	→ Chapter 5.3.6,  27
D Ethernet	→ Chapter 5.3.5,  26
E Interfaces, depending on the device version:	
USB Host	→ Chapter 5.3.7,  27
SmartWire-DT Master	→ Chapter 5.3.8,  28
CAN	→ Chapter 5.3.9,  34
Profibus	→ Chapter 5.3.10,  37
RS232 (System Port)	→ Chapter 5.3.4,  24
RS485	→ Chapter 5.3.11,  39
F Power supply	→ Chapter 5.3.3,  23

Tab. 5 Overview of interfaces

5.3.2

Preparation of cables with D-Sub connector

The preparation of bus cables is an essential factor in ensuring reliable operation and electromagnetic compatibility (EMC).

Wiring requirements

- The cables must be shielded.
- The cable shield must be made from a copper braid.
- The cable shield must make a low impedance connection with the connector casing over a large contact area. This is achieved by:
 - Use of metal or metallized connector casings with a cable clamp for strain relief.
 - The cable clamp must be screwed securely to the connector.

Connecting the cable shield




Fig. 5 Connecting the cable shield

- 1 Strip the cable end so that approx. 3 cm of the shield braid is exposed.
- 2 Fold back the shield braid over the cable shield.
- 3 Fit approx. 3 cm of heat shrinkable tubing over the folded back end of the shield braid or use a rubber grommet.
 - 5...8 mm of the shield braid must be exposed at the cable end.
 - The folded back shield braid end must be covered by the heat shrinkable tubing or by the rubber grommet.
- 4 Fit the D-Sub connector to the cable end:
 - The exposed metal shield braid must be clamped to the connector casing with the cable clamp.

5 Installation

5.3 Interfaces




Fig. 6 Cable prepared with D-Sub connector

- | | |
|--|----------------------|
| A Cable with cable sheath | D Shield braid |
| B Heat shrinkable tubing or rubber grommet | E D-Sub connector |
| C Cable clamp | F Mounting screw UNC |



The EMC values stated in the technical data (immunity and emission) can only be guaranteed by observing the prescribed cable preparation!

5.3.3

Power supply

The device is provided with an internal fuse and is protected against polarity reversal. The functional earthing terminal is connected exclusively to the connector cover and not to the 0 V. The housing is made from plastic and is isolated. The device power supply is **not** electrically isolated.

The device requires a 24 VDC power supply from an AC/DC converter with safe isolation (SELV). For other power supply requirements see Chapter 9.3.1 Power supply, 53.

- SELV (safety extra low voltage):
Circuit in which no dangerous voltage is present, even in the event of a single fault.




Fig. 7 Power supply interface

Wiring

- Phoenix Contact MSTB 2.5/3-ST-5.08 connector, Phoenix order no. 1757022 is supplied with the device.




Fig. 8 Phoenix Contact MSTB 2.5/3-ST-5.08 connector (view from the wiring side)

Connection	Assignment
+24 VDC	+24 VDC power supply
⊕	Functional earthing connected with connector cover. Does not have to be connected. This connection can be used as protective earthing connection if the mounting environment requires this.
0 V	0 V power supply

Tab. 6 Assignment of connector

- The following must be observed when the connector wiring is prepared:

Preparing the wiring of the connector

Terminal type	Pluggable screw terminal
Cross-section	<ul style="list-style-type: none"> ■ min. 0.75 mm² / max. 2.5 mm² (lead or wire) ■ min. AWG18 / max. AWG12
Stripping length	7 mm
Max. tightening torque	0.6...0.8 Nm / 5...7 Lb. In.

Tab. 7 Preparing the wiring of the connector


5 Installation

5.3 Interfaces

5.3.4

RS232 (System Port)

The RS232 interface is **not** electrically isolated.

CAUTION	
	<p>Non-isolated interfaces</p> <p>The device may be damaged due to potential differences.</p> <p>▶ The GND terminals of all bus stations must be connected.</p>




Fig. 9 RS232 interface (9-pin, D-Sub, male, UNC)

Pin	Signal	Assignment
1	DCD	Data Carrier Detected
2	RxD	Receive Data
3	TxD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request to Send
8	CTS	Clear to Send
9	RI	Ring Indicator

Tab. 8 Pin assignment of the RS232 interface

Wiring

- Shielded cables must be used.
- The maximum baud rate depends on the cable length:

Cable length	Max. baud rate
2.5 m	115200 Bit/s
5 m	57600 Bit/s
10 m	38400 Bit/s
15 m	19200 Bit/s
30 m	9600 Bit/s

Tab. 9 Relationship of cable length / baud rate



When preparing the cables, ensure that there is a low-resistance connection between the cable shield and the connector casing (→ Chapter 5.3.2, 21).

5 Installation
5.3 Interfaces

5.3.5

Ethernet




Fig. 10 Ethernet interface (RJ45 socket)


LED	Signal	Meaning
ACT (yellow)	flashes	Ethernet is active (data traffic)
LINK (green)	lit	Active network is connected and detected

Tab. 10 Control LEDs of the Ethernet interface

Cable

- Use shielded twisted pair cable (STP) for networking:
 - For device to device connection: crossover cable
 - For connecting to the hub/switch: 1:1 patch cable
- Maximum cable length: 100 m.

CAUTION



Forces acting on the Ethernet interface

Communication can be disturbed and the connection mechanics damaged if the Ethernet interface is exposed to severe vibration or the RJ45 plug connection is pulled.

- ▶ Protect the RJ45 connection from severe vibration.
- ▶ Protect the RJ45 connection from pulling on the socket.

5.3.6

USB Device

The USB Device interface supports USB 2.0.



Fig. 11 USB Device interface (USB Device, type B)

Cable

- Only use shielded USB standard cable.
- Maximum cable length: 5 m.

5.3.7

USB Host

The USB Host interface supports USB 2.0.




Fig. 12 USB Host interface (USB Host, type A)

Cable

- Only use shielded USB standard cable.
- Maximum cable length: 5 m.


5 Installation

5.3 Interfaces

5.3.8

SmartWire-DT Master

The SmartWire-DT Master interface is **not** electrically isolated.

CAUTION	
	<p>Not electrically isolated SmartWire-DT system</p> <p>The device may be damaged due to potential differences.</p> <p>▶ Provide a common star point for the earth wiring.</p>

5.3.8.1

Additional documentation for devices with SmartWire-DT Master interface

In addition to this document, the following documents are required to build a SmartWire-DT network, to install the network at the SmartWire-DT Master interface and to operate the network. These can be downloaded from www.moeller.net, «Support» section and from www.eaton.eu (search document No. via search field of the home page).

- MN05006002Z-EN Manual SmartWire-DT The System
(system description, engineering, installation, commissioning and diagnostics of a SmartWire-DT network)
- MN05006001Z-EN Manual SmartWire-DT Units
(surface mounting, engineering, installation, etc. of the single SmartWire-DT slaves)
- MN05003007Z-EN User Manual XSoft-CoDeSys-2: PLC Programming XC-152
(use of the PLC programming tool XSoft-CoDeSys-2 and the PLC runtime system for the XC-152 device type with Windows CE)

5.3.8.2

Operating and indication elements of the SmartWire-DT Master interface




Fig. 13 SmartWire-DT Master interface

Element	Function
A POW/AUX interface	Power supply interface for SmartWire-DT (→ Chapter 5.3.8.3, 30)
B POW LED	Lit if the SmartWire-DT network is supplied with current.
C SWD LED	Indicates whether the physical structure of the SmartWire-DT network matches the target configuration. Each time the power supply is switched on, the configurations are compared (→ Chapter 5.3.8.5, 32).
D Config LED	Indicates whether the project configuration of the SWD master defined in the PLC matches the target configuration of the SmartWire-DT network stored in the device. Each time the power supply is switched on, the configurations are compared (→ Chapter 5.3.8.5, 32).
E Configuration button	Configuring the SmartWire-DT network.
F SWD interface	SmartWire-DT interface (→ Chapter 5.3.8.4, 31)

Tab. 11 Operating and indication elements of the SmartWire-DT Master interface

5 Installation

5.3 Interfaces


5.3.8.3

POW/AUX (power supply for SmartWire-DT)

The POW/AUX interface is **not** electrically isolated.

The following supply voltages are required in a SmartWire-DT network:

- Supply voltage POW:
The device supply voltage for the electronics of the downstream SmartWire-DT slaves (15 VDC) is generated from the 24 VDC supply voltage applied to the POW connection.
- Supply voltage AUX:
If there are any contactors or motor starters in the SmartWire-DT topology, a 24 VDC voltage AUX must be additionally supplied as a control voltage for the contactor coils.

For other power supply requirements see Chapter 9.3.2 SmartWire-DT Master,  54.




Fig. 14 Power supply interface POW/AUX

Wiring

- WAGO connector, order no. 734-104 is supplied with the device.




Fig. 15 WAGO connector (view from the wiring side)

Connection	Assignment
+24 VDC POW	Supply voltage U_{POW} +24 VDC
0 V POW	Supply voltage U_{POW} 0 V
+24 VDC AUX	Supply voltage U_{AUX} +24 VDC
0 V AUX	Supply voltage U_{AUX} 0 V

Tab. 12 Assignment of connector

- The following must be observed when the connector wiring is prepared:

Preparing the wiring of the connector

Terminal type	Tension clamp terminal
Crimpable wire solid	0.2...1.5 mm ² (AWG24...16)
Stripping length	6...7 mm

Tab. 13 Preparing the wiring of the connector

- For U_{Aux} , an external over-current and short-circuit protection by miniature circuit-breaker or fuse is required.

Standard	Over-current and short-circuit protection
DIN VDE 0641, Part 11 and IEC/EN 60898	Miniature circuit-breaker 24 VDC, rated current 3 A, tripping characteristic Z Fuse 3 A, utilization class gL/gG
UL 508 and CSA-22.2, No. 14	Miniature circuit-breaker 24 VDC, rated current 2 A, tripping characteristic Z Fuse 2 A

Tab. 14 Over-current and short-circuit protection

5.3.8.4

SWD (SmartWire-DT interface)

Die SWD interface is **not** electrically isolated.




Fig. 16 SWD interface (plug, 8-pin)

Cabling

- Use only the following ribbon cables for connecting the SmartWire-DT network at the SWD interface:
 - SWD4-100LF8-24 with the relevant blade terminals SWD4-8MF2 or
 - SWD4-(3/5/10)F8-24-2S (prefabricated cable)
- ☞ **Detailed instructions on fitting the blade terminal SWD4-8MF2 are provided in the Document «MN05006002Z-EN Manual SmartWire-DT The System», Chapter «Fitting the blade terminal SWD4-8MF2».**

5 Installation

5.3 Interfaces

5.3.8.5

Commissioning of the SmartWire-DT network

Switching on for initial commissioning, after a replacement or after a changed SmartWire-DT configuration

Requirement:

- All SmartWire-DT slaves are connected by SmartWire-DT cables.
- The SmartWire-DT network is connected to the SWD interface.
- The power supply for the device and for SmartWire-DT is applied.
- The POW LED of the SmartWire-DT Master interface lights up.
- The SmartWire-DT status LEDs on the connected SmartWire-DT slaves are flashing or lit.
- A PLC project with configured SWD-Master exists (project configuration).
- The PLC runtime system is installed on the device.

Procedure:

- 1 Press the configuration button «Config» for at least two seconds.
 - The SWD LED of the SmartWire-DT Master interface begins to flash orange and the SmartWire-DT status LEDs on the connected SmartWire-DT slaves flash.
 - The SWD LED of the SmartWire-DT Master interface begins to flash green.
 - All SmartWire-DT slaves are addressed.
 - The physical structure of the SmartWire-DT network is stored retentively in the device as the target configuration.
 - The SWD LED of the SmartWire-DT Master interface lights up green.
- 2 Download the PLC project (XSoft-CoDeSys-2) onto the device.
 - If the project configuration is identical to the stored target configuration, the Config LED lights up green and the data exchange of the input and output data can start.

Configuration check

Each time the supply voltage is switched on, the configuration checks are performed:

- 1 The slaves actually found on the network are compared with the target configuration stored in the device.
 - If the physical structure of the SmartWire-DT network matches the target configuration, the SmartWire-DT network is ready for data exchange.
- 2 The target configuration stored in the device is compared with the project configuration defined in the PLC.
 - If the target configuration matches the project configuration, the Config LED lights up.

LED	State	Meaning
SWD	Off	No target configuration.
	Red continuous light	<ul style="list-style-type: none"> ■ Short-circuit on the 15 VDC power supply. ■ No SmartWire-DT slave found.
	Red flashing	<ul style="list-style-type: none"> ■ The slaves found in the SmartWire-DT network do not match the target configuration. ■ A SmartWire-DT slave configured as necessary is missing.
	Orange flashing	The physical structure of the SmartWire-DT network is read and stored as the target configuration.
	Green flashing	<ul style="list-style-type: none"> ■ The physical structure of the SmartWire-DT network is compared with the target configuration. ■ The SmartWire-DT slaves are addressed.
	Green continuous light	The slaves found in the SmartWire-DT network match the target configuration. The SmartWire-DT network is ready for data exchange.
Config	Off	<ul style="list-style-type: none"> ■ No project configuration. ■ Faulty target configuration (see SWD LED).
	Red continuous light	Project configuration and stored target configuration are not compatible.
	Green flashing	Project configuration and stored target configuration are compatible.
	Green continuous light	Project configuration and stored target configuration are identical.

Tab. 15 SWD LED and Config LED



The description of the project configuration (SmartWire-DT configuration in XSoft-CoDeSys-2 project) are provided in the Document «MN05003007Z-EN User Manual XSoft-CoDeSys-2: PLC Programming XC-152», Chapter «SmartWire-DT configuration».


5 Installation

5.3 Interfaces

5.3.9

CAN

The CAN interface is **not** electrically isolated.

CAUTION	
	<p>Non-isolated interfaces</p> <p>The device may be damaged due to potential differences.</p> <p>▶ The GND terminals of all bus stations must be connected.</p>




Fig. 17 CAN interface (9-pin, D-Sub, male, UNC)

Pin	Signal	Assignment
1	-	nc
2	CAN-L	Bus line (dominant low)
3	CAN-GND	CAN Ground
4	-	nc
5	-	nc
6	GND	Optional CAN Ground
7	CAN-H	Bus line (dominant high)
8	-	nc
9	-	nc

Tab. 16 Pin assignment of CAN interface in accordance with CiA



- Pin 3 (CAN-GND) and 6 (GND) are connected internally in the device.
- nc: Pins 1, 4, 5, 8 and 9 must not be connected.
- The CAN bus drivers are fed internally with power.
- No power supply for third-party devices is implemented on the CAN connector.

Wiring

- Shielded twisted pair cables must be used.

Cable specifications


Rated surge impedance	120 Ω
Permissible surge impedance	108... 132 Ω
Capacitance per unit length	< 60 pF/m
Core cross-section / max. cable length	≥ 0.25 mm ² / 100 m
	≥ 0.34 mm ² / 250 m
	≥ 0.75 mm ² / 500 m

Tab. 17 Cable specifications


- The maximum baud rate depends on the cable length:

Cable length	Max. baud rate
25 m	1000 Kbit/s
50 m	800 Kbit/s
100 m	500 Kbit/s
250 m	250 Kbit/s
500 m	125 Kbit/s
500 m	100 Kbit/s (adjustable via software)
1000 m	50 Kbit/s
2500 m	20 Kbit/s
5000 m	10 Kbit/s

Tab. 18 Relationship of cable length / baud rate

- 
 - **The use of repeaters is recommended with cables over 1000 m in length. Repeaters can also be used to implement electrical isolation. Refer to the documentation of the repeater manufacturer for further information.**
 - **Observe the recommendations of the CiA (CAN in Automation).**
 - **When preparing the cables, ensure that there is a low-resistance connection between the cable shield and the connector casing (→ Chapter 5.3.2, 21).**

CAN bus topology

- A bus segment can connect up to 32 bus stations.
- Several bus segments can be linked via repeaters (bidirectional amplifiers). Refer to the documentation of the repeater manufacturer for further information.
- A bus segment must be provided with cable termination (120 Ω) at both ends. These terminations must be connected in the connector, directly between pin 2 and 7.
- 
 - **The bus segment must be terminated at both ends.**
 - **No more than two terminations must be provided on each bus segment.**
 - **Transmission faults can occur if operation is carried out without the correct termination.**

5 Installation

5.3 Interfaces





Fig. 18 Bus segment with four bus stations

5.3.10

Profibus

The Profibus interface is **not** electrically isolated.

CAUTION	
	<p>Non-isolated interfaces</p> <p>The device may be damaged due to potential differences.</p> <p>▶ The GND terminals of all bus stations must be connected.</p>




Fig. 19 Profibus interface (9-pin, D-Sub, female, UNC)

Pin	Signal	Assignment
1	-	nc
2	-	nc
3	B	EIA RS 485 line B
4	RTSAS	Output for controlling a repeater
5	M5EXT	0V output for external termination
6	P5EXT	5V output for external termination
7	-	nc
8	A	EIA RS 485 line A
9	-	nc

Tab. 19 Pin assignment of the Profibus interface

 **Pin 6 (5 V) must not be used as a power supply for external devices.**

Wiring

- Shielded twisted pair cables, cable type A (in accordance with Profibus standards IEC/EN 61158 and IEC/EN 61784) must be used.

Cable specifications

Rated surge impedance	150 Ω
Permissible surge impedance	135... 165 Ω
Capacitance per unit length	< 30 pF/m
Loop resistance	< 110 Ω /km
Core cross-section	$\geq 0.34 \text{ mm}^2$ (22 AWG)

Tab. 20 Cable specifications

5 Installation
5.3 Interfaces

- The maximum baud rate depends on the cable length:

Cable length	Max. baud rate
200 m	1500 Kbit/s
400 m	500 Kbit/s
1000 m	187.5 Kbit/s
1200 m	≤ 93.75 kBit/s

Tab. 21 Relationship of cable length / baud rate (for cables compliant with cable type A of the Profibus standard IEC/EN 61158 and IEC/EN 61784)

- ☞ **When preparing the cables, ensure that there is a low-resistance connection between the cable shield and the connector casing (→ Chapter 5.3.2, 21).**

Profibus topology

- A bus segment can connect up to 32 bus stations.
- Several bus segments can be linked via repeaters (bidirectional amplifiers). Refer to the documentation of the repeater manufacturer for further information.

- ☞ **The maximum cable length can be increased by using repeaters. Refer to the documentation of the repeater manufacturer for further information.**

- Only use bus terminal connectors that are specified for use in the Profibus network. They hold both bus cables on a bus station and ensure a low impedance connection of the cable shield to the shield reference potential of the bus station. These bus terminal connectors contain the Profibus cable termination that can be switched on as required.
- A bus segment must be provided with cable termination at both ends. The termination is passive and is fed from the bus station. It ensures a defined idle signal on the bus when no bus station is transmitting. These bus terminations should be implemented externally in the connector casing according to the Profibus standard (they can also be implemented with the bus terminating connector described above).





Fig. 20 Bus segment with four bus stations

- ☞ **■ The bus segment must be terminated at both ends.**
- No more than two terminations must be provided on each bus segment.
- At least one of the two terminations must be fed by the bus station.
- Transmission faults can occur if operation is carried out without the correct termination on the Profibus network.

5.3.11

RS485

The RS485 interface is **not** electrically isolated.

CAUTION	
	<p>Non-isolated interfaces</p> <p>The device may be damaged due to potential differences.</p> <p>▶ The GND terminals of all bus stations must be connected.</p>





Fig. 21 RS485 interface (9-pin, D-Sub, male, UNC)

Pin	Signal	Assignment
1	-	nc
2	-	nc
3	B	Line B
4	-	nc
5	GND	Ground
6	-	nc
7	A	Line A
8	-	nc
9	-	nc

Tab. 22 Pin assignment of the RS485 interface

 **nc: Pins 1, 2, 4, 6, 8 and 9 must not be connected.**


5 Installation
5.3 Interfaces

Wiring

Shielded twisted pair cables must be used.


Cable specifications	
Rated surge impedance	120 Ω
Permissible surge impedance	108... 132 Ω
Max. cable length	1200 m
Possible baud rates	9600 Bit/s
	19200 Bit/s
	38400 Bit/s
	57600 Bit/s
	115200 Bit/s

Tab. 23 Cable specifications


 **When preparing the cables, ensure that there is a low-resistance connection between the cable shield and the connector casing (→ Chapter 5.3.2, 21).**

RS485 topology

- A bus segment can connect up to 32 bus stations.
- Several bus segments can be linked via repeaters (bidirectional amplifiers). Refer to the documentation of the repeater manufacturer for further information.

 **The maximum cable length can be increased by using repeaters. Refer to the documentation of the repeater manufacturer for further information.**

- A bus segment must be provided with cable termination (120 Ω) at both ends. These terminations must be connected directly between pin 3 and 7 in the connector.

-  ■ **The bus segment must be terminated at both ends.**
- **No more than two terminations must be provided on each bus segment.**
 - **Transmission faults can occur if operation is carried out without the correct termination.**




Fig. 22 Bus segment with four bus stations

5.4

Mounting the device

CAUTION**Operational malfunctions**

Use of unsuitable or improperly prepared cables, as well as incorrect wiring will mean that neither the values stated in the technical data nor the electromagnetic compatibility (EMC) can be ensured.

- ▶ Only use cables prepared by specialists.
- ▶ The cables used must be prepared according to the interface description in this document.
- ▶ The wiring instructions for the relevant interface must be observed when wiring the device.
- ▶ Any generally applicable regulations and standards must be fulfilled.

CAUTION**Device condensation**

If the device is or was exposed to climatic changes (temperature fluctuation, air humidity) moisture can form on or in the device (device condensation). In this case, there is a risk of short-circuit.

- ▶ The device must **not** be switched on when device condensation is present.
- ▶ If condensation is present on the device, or if it was exposed to temperature fluctuations, it must be allowed to adjust to room temperature (do not expose the device to the direct heat of heating devices) prior to commissioning.

- 1 Check the device for damage in transit.



The device must only be installed and commissioned in perfect technical condition and in compliance with this document.

- 2 Select the mounting position of the device in the control cabinet as described in Chapter 5.2.2 Requirements for the mounting position, 18.
- 3 Mount the device:
 - Mount the device on a top-hat rail, see Chapter 5.4.1, 42.
 - Mount the device with fixing brackets (screw mounting), see Chapter 5.4.2, 43.
- 4 Connect the device as required.
 - Follow the instructions on wiring the relevant interface. See Chapter 5.3 Interfaces, 19.



The device is not provided with an On/Off switch. If the power supply is not provided with a switch, the device will start up (boot) as soon as it is connected to the power supply.

5 Installation

5.4 Mounting the device

5.4.1

Mounting and removing the device on a top-hat rail

Mounting the device on a top-hat rail




Fig. 23 Mounting the device on a top-hat rail

- 1 Hook the device onto the top-hat rail from above.
- 2 Press the bottom of the device against the top-hat rail until the device snaps into place.
- 3 Press the locking slider in direction of the rear of the device to ensure, the top-hat rail is fixed correctly.
 - The device must be firmly fitted on the top-hat rail.




Fig. 24 Device mounted on a top-hat rail

Removing the device on a top-hat rail




Fig. 25 Removing the device on a top-hat rail

- 1 Pull both locking sliders downwards by a screw driver so that they snap into place.
- 2 Remove the device from the top-hat rail.

5.4.2

Mounting the device with fixing brackets (screw mounting)

- 1 Insert the four fixing brackets into the corresponding fixing points at the rear of the device.
- 2 Press the fixing brackets into the fixing points until they snap into place.
- 3 Mount the device by fixing screws at the desired position.






Fig. 26 Device with four fixing brackets


5 Installation

5.4 Mounting the device


6 Operation

6.1 Safety regulations

 Read Chapter 3 Safety regulations,  9 before working with the device. This contains important information for your personal safety.


CAUTION	
	<p>Device condensation</p> <p>If the device is or was exposed to climatic changes (temperature fluctuation, air humidity) moisture can form on or in the device (device condensation). In this case, there is a risk of short-circuit.</p> <ul style="list-style-type: none"> ▶ The device must not be switched on when device condensation is present. ▶ If condensation is present on the device, or if it was exposed to temperature fluctuations, it must be allowed to adjust to room temperature (do not expose the device to the direct heat of heating devices) prior to commissioning.

6.2 Starting the device

 The starting of the device by DHCP function can be forced as follows:

- While switching on the device, hold down the CTRL button until the SF LED is solid green.

In this mode, the files Autoexec.bat, Autoexec.reg and Autoexec.bmp are not executed.

- 1 Energize the device.
 - The device will boot.
- 2 If the device does not boot up and/or if an error message appears while starting (booting) the device, see Chapter 7.4 Troubleshooting,  48.
- 3 Complete the following steps after initial commissioning (→ Document «MN05010007Z-EN System Description Windows CE»):
 - 3.1 Adjust the system settings of the device.
 - 3.2 Install the required application programs.

6.3 Switching off the device

- 1 De-energize the device.

6 Operation

6.4 Inserting and removing an SD card

6.4

Inserting and removing an SD card




Fig. 27 SD slot (A)

CAUTION



Data loss

During a write operation, the SD card may lose data or may be destroyed if it is removed or if there is a power failure.

- ▶ Only insert the SD card when the device is in a de-energized state.
- ▶ Avoid write operations to SD cards. Reasons:
 - The number of write cycles possible on SD cards is limited.
 - A power failure during write operations will most likely lead to loss of data.
- ▶ Only remove the SD card when the device is in a de-energized state.
- ▶ Before switching off, ensure that no software write operations to the SD card are in progress.



Do not apply any force (SD cards are protected against reverse insertion).

Inserting the SD card

- 1 Push the SD card into the SD slot (A) until it snaps into position.

Removing the SD card

- 1 Push the SD card in the SD slot (A) all the way in.
 - This releases the lock mechanism and the SD card comes out of the SD slot a little.
- 2 Remove the SD card from the SD slot.

7 Maintenance and service

7.1 Safety regulations



Read Chapter 3 Safety regulations, 9 before working with the device. This contains important information for your personal safety.

7.2 Maintenance

7.2.1 Battery

The integrated battery cannot be exchanged. Lifespan, see Chapter 9.2 System, 52.

7.3 Service

7.3.1 Repairs

The device must only be opened by the manufacturer or by an authorized repair center.

Contact your local supplier or Eaton technical support for repairs.

Only the original packaging should be used for transporting the device.

7 Maintenance and service

7.4 Troubleshooting

7.4

Troubleshooting



LED state red indicates an exceptional operating condition.

LED state			Fault and possible cause	Corrective action
RUN/STOP	SF	COM		
While the device is starting (booting)				
Off	Off	Off	Power supply interface does not have any power.	Check the power supply cable.
Orange	Orange	Orange	<ul style="list-style-type: none"> ■ Jumper UPD/RUN is misplaced. ■ Hardware failure 	<ul style="list-style-type: none"> ■ Set jumper UPD/RUN to position RUN. ■ If jumper UPD/RUN is set to position RUN, send in your device for repair.
Orange	Any	Orange flashing	The SD slot does not contain a SD card.	<ul style="list-style-type: none"> ■ Insert the SD card with the operating system in the SD slot. ■ By pressing the CTRL button, the device can be started from the internal OS.
Orange	Any	Red flashing	The OS on the SD card is too old or could not be found.	<ul style="list-style-type: none"> ■ Copy a new OS on the SD card. ■ By pressing the CTRL button, the device can be started from the internal OS.
Orange	Orange	Off	Boot error. Occurs when: <ul style="list-style-type: none"> ■ an invalid OS is saved in the InternalStorage. ■ the internal OS has been started due to pressing the CTRL button (OS from the InternalStorage). 	<ul style="list-style-type: none"> ■ Save a valid OS into the InternalStorage. ■ Save a valid OS onto the SD card.
During operation				
Off	Off	Off	Power supply interface does not have any power.	Check the power supply cable.
Orange	Orange	Orange	<ul style="list-style-type: none"> ■ Jumper UPD/RUN is misplaced. ■ Hardware failure 	<ul style="list-style-type: none"> ■ Set jumper UPD/RUN to position RUN. ■ If jumper UPD/RUN is set to position RUN, send in your device for repair.
Orange/green flashing			No PLC program is available.	Save a PLC program on the device.
Orange	Red		PLC system fault	Check the PLC program.

Tab. 24 Troubleshooting

8 Storage, transport and disposal

8.1 Safety regulations



Read Chapter 3 Safety regulations, § 9 before installing and commissioning the device. This contains important information for your personal safety.

8.2 Storage

The ambient conditions for storage must be fulfilled. See Chapter 9.7 Ambient conditions, § 57.

8.3 Transport

Damage to the device must be prevented during transport (use an appropriate packaging).

The ambient conditions must be fulfilled even when the device is transported. See Chapter 9.7 Ambient conditions, § 579.7 Ambient conditions, § 57.



- 1 Check the device on arrival for damage in transit.

8 Storage, transport and disposal

8.4 Disposal

8.4

Disposal

 DANGER	
	<p>Explosive and toxic materials</p> <p>Any improper handling causes a risk of explosion due to the lithium battery soldered in the device.</p> <p>▶ Dispose of the device properly.</p>

Devices that are no longer used must be properly disposed of in accordance with the applicable national regulations or returned to the manufacturer or sales office.

Materials used in the device

Component	Material
Housing	PC-GF
Battery	Lithium
Electronic components	Various

Tab. 25 Materials used in the device



The materials used for our housings are halogen-free.

Materials used in the packaging

Packaging	Material
External packaging	Cardboard
Internal packaging:	<ul style="list-style-type: none"> ■ Cardboard with PE foil ■ Plastic bag: Polyethylene (PE)

Tab. 26 Materials used in the packaging

9 Technical data

9.1 Dimensions and weights




Fig. 28 Mechanical dimensions in mm

Property	XC-152
Height	
Device without fixing brackets	105.6 mm
Device with fixing brackets	121.2 mm
Width	
	155.1 mm
Depth	
Device without fixing brackets	41.5 mm (XC-152-E...: 50.6 mm)
Device with fixing brackets	43 mm (XC-152-E...: 52.1 mm)
Weight	
	Approx. 0.3 kg

Tab. 27 Dimensions and weights

9 Technical data

9.2 System

9.2

System

Property	XC-152
Processor	RISC, 32-bit, 400 MHz
Internal memory	
DRAM	64 MByte
NAND Flash	64 MByte
NVRAM	125 KByte
External memory	
SD memory card slot	1× SDA specification 1.00 Suitable for SD cards (not for SDHC cards or cards of newer standard) Use only original accessories.
Real-time clock (battery backup)	
Battery type	CR2032 (190 mA/h), maintenance-free (soldered)
Backup time in de-energized state	Normally 10 years

Tab. 28 System

9.3

Interfaces

Property	XC-152
Ethernet	100Base-TX / 10Base-T
USB Device	USB 2.0, not electrically isolated
Interfaces, depending on the device version:	
USB Host	USB 2.0 (1.5 / 12 / 480 MBit/s), not electrically isolated
SmartWire-DT Master	SmartWire-DT, not electrically isolated → Chapter 9.3.2, 54
RS232 (System Port)	RS232, not electrically isolated
CAN	CAN, not electrically isolated
Profibus	Profibus, not electrically isolated, max. 1.5 Mbit/s
RS485	RS485, not electrically isolated
Power supply	→ Chapter 9.3.1, 53
DIAG	Only for service tasks
Jumper UPD/RUN	Only for service tasks

Tab. 29 Interfaces

9.3.1

Power supply

Property	XC-152
Rated voltage	24 VDC SELV (safety extra low voltage)
Permissible voltage	<ul style="list-style-type: none"> ■ RMS value: 20.4 ... 28.8 VDC (rated voltage -15 % / +20 %) ■ Absolute with ripple: 19.2 ... 30.0 VDC ■ Battery operation: 19.2 ... 30.0 VDC (rated voltage -20 % / +25 %)
Voltage dips	<ul style="list-style-type: none"> ■ 10 ms from rated voltage (24 VDC) ■ 5 ms from undervoltage (20.4 VDC)
Power consumption	
Basic device	Max. 6 W
USB stations on USB host	Max. 2.5 W
Total	Max. 8.5 W
Current consumption	
Continuous current	Max. 0.35 A (24 VDC)
Starting current inrush	1.5 A ² s
Protection against reverse polarity	Yes
Fuse	Yes (replacement only by the manufacturer or by an authorized repair center)
Potential isolation	No

Tab. 30 Power supply

9 Technical data

9.3 Interfaces

9.3.2 SmartWire-DT Master

9.3.2.1 POW/AUX (power supply interface for SmartWire-DT)

Property	XC-152
Supply voltage U_{Aux} (control voltage for contactor coils)	
Operating voltage	
Rated voltage	24 VDC
Permissible voltage	RMS value: 20.4 ... 28.8 VDC (rated voltage -15 % / +20 %)
Input voltage residual ripple	Max. 5 %
Protection against reverse polarity	Yes
Current	
In accordance with DIN VDE 0641, Part 11 and IEC/EN 60898	Max. 3 A ¹⁾
In accordance with UL 508 and CSA-22.2, No. 14	Max. 2 A ¹⁾
Short-circuit strength	No, external protection required (e. g. FAZ Z3, → Chapter 5.3.8.3, 30)
Power loss	Normally 1 W
Potential isolation	No
Rated operating voltage of 24 VDC slaves	Normally $U_{Aux} - 0.2$ V
Supply voltage U_{Pow} (for SmartWire-DT slaves)	
Supply voltage	
Rated voltage	24 VDC
Permissible voltage	RMS value: 20.4 ... 28.8 VDC (rated voltage -15 % / +20 %)
Input voltage residual ripple	Max. 5 %
Protection against reverse polarity	Yes
Current	Max. 0.7 A
Overload proof	Yes
Inrush current and length	12.5 A/6 ms
Power loss at 24 VDC	1.0 W
Potential isolation between U_{Pow} and 15 V SmartWire-DT supply voltage	No
Bridging voltage dips	10 ms

Property	XC-152
Repetition rate	1 s
Status indication	Yes (LEDs)

Tab. 31 POW/AUX (power supply interface for SmartWire-DT)

- 1) If contactors and/or motor starters with a total power consumption > 3 A (DIN VDE 0641, Part 11 and IEC/EN 60898) or > 2 A (UL 508 and CSA-22.2, No. 14) are connected, a power feeder module EU5C-SWD-PF1 or EU5C-SWD-PF2 has to be used.

9.3.2.2

SWD (SmartWire-DT interface)

Property	XC-152
SmartWire-DT supply voltage U_{VP}	
Rated operating voltage (internally transformed supply voltage U_{POW})	14.5 VDC $\pm 3\%$ (14.0... 15.0 VDC)
Current	Max. 0.7 A ¹⁾
Short-circuit strength	Yes
Number of SmartWire-DT slaves on the SmartWire-DT network	Max. 99
Address setting of the SmartWire-DT slaves	Automatic
Baud rate	<ul style="list-style-type: none"> ■ 125 Kbit/s ■ 250 Kbit/s

Tab. 32 SWD (SmartWire-DT interface)

- 1) If SmartWire-DT slaves with a total power consumption > 0.7 A are connected, a power feeder module EU5C-SWD-PF2 has to be used.

9 Technical data

9.4 Enclosure ratings

9.4 Enclosure ratings

Property	XC-152
Device	IP20, Open Type

Tab. 33 Enclosure ratings

9.5 Agency approvals and standards

Property	XC-152
EMC	2004/108/EC
UL	UL 508, file no. E205091

Tab. 34 Agency approvals and standards

9.6 Applicable standards and regulations

Property	XC-152
EMC (in relation to CE)	
IEC/EN 61000-6-2	Immunity for industrial areas
IEC/EN 61000-6-4	Emission for industrial environments
IEC/EN 61131-2	Programmable logic controllers, equipment requirements and tests
Safety	
UL 508	Industrial control equipment (Engineering conditions of acceptability by UL, → Kapitel 5.2.1, 18)
Product standards	
EN 50178	Electronic equipment for use in power installations
IEC/EN 61131-2	Programmable logic controllers, equipment requirements and tests

Tab. 35 Applicable standards and regulations

9.7

Ambient conditions

Property	XC-152
Temperature	
Operation	0 ... 55°C
Storage / Transport	-20 ... 60°C
Relative air humidity	5...95%, non-condensing
Vibration in accordance with IEC/EN 60068-2-6	Displacement: ■ 5...8.4 Hz: 3.5 mm Acceleration: ■ 8.4... 150 Hz: 1 g
Schock in accordance with IEC/EN 60068-2-27	15 g / 11 ms
Fall test	In accordance with IEC/EN 60068-2-31

Tab. 36 Ambient conditions

9 Technical data

9.7 Ambient conditions