




# Double vane pumps

## Overall instructions

### T7 - T67 - T6 series

### B - C - D - E sizes



Publ. S1 - EN0547 - A

06 / 2002 / FB

Replaces :

L23 - 10547 - 1

**DENISON** | Hydraulics

**1 . START-UP INSTRUCTIONS & RECOMMENDATIONS**

1 . 1 . General & start-up check-up ..... 3  
 1 . 2 . Shaft & coupling data ..... 4  
 1 . 3 . Specific points ..... 4  
 1 . 4 . Fluids ..... 5

**2 . PUMP & CARTRIDGE BREAKDOWN DRAWING ..... 6**

**3 . CONVERSIONS**

3 . 1 . Complete disassembly of the pump ..... 7 to 12  
 3 . 2 . Changing rotation ..... 13 to 16  
 3 . 3 . Complete reassembly of the pump ..... 17 to 21  
 3 . 4 . Changing porting P1 ..... 22 to 24  
 3 . 5 . Changing porting P2 ..... 25 to 26

**4 . KEY SHEET, TORQUES & PORTING TABLES**

4 . 1 . Key sheet ..... 27  
 4 . 2 . Torque requirements ..... 27  
 4 . 3 . Porting tables ..... 28

**5 . SPECIAL TOOLS**

5 . 1 . Seal driver - Dimensions ..... 29  
 5 . 2 . Protective cone - Dimensions ..... 29 to 30

**6 . COUPLINGS**

6 . 1 . Female coupling dimensions ..... 31

**7 . VANE TROUBLESHOOTING GUIDE ..... 32 to 35**

## 1 . 1 . GENERAL :

All DENISON Hydraulics vane pumps & motors are individually tested to provide the best quality & reliability. Modifications, conversions & repairs can only be done by authorized dealers or OEM to avoid invalidation of the guarantee.

The pumps & motors are to be used in the design limits indicated in all the sales bulletins. Please contact DENISON when trespassing the catalog limits.

Do not modify or work on the pump (or motor) under pressure or when the electric motor (or any drive) is on.

Qualified personnel is required to assemble and set-up hydraulic devices.

Always conform yourself to the valid regulations (safety, electrical, environment...).

The following instructions are important to follow to obtain a good service life time from the unit.

## ROTATION & PORTS INDICATION

The rotation and ports orientation are viewed from the shaft end.

CW stands for clockwise, right-hand rotation.

CCW stands for counter-clockwise, left-hand rotation.

## START-UP CHECK-UP

### Check that the assembly of the power unit is correct :

The distance between the suction pipe & the return lines in the tank should be at its maximum.

A bevel on both suction & return lines is recommended to increase the surface and so lower the velocity. We suggest a 45° minimum angle.

Velocities : inlet  $0,5 < x < 1,9$  m/s (1,64 < x < 6,23 ft per sec.)  
 : return  $x < 6$  m/s (x < 19,7 ft per sec.)  
 : Always insure that all return and suction lines are under the oil level to avoid forming aeration or vortex effect. This should be done under the most critical situation (all cylinders extended for example). Straight and short pipes are the best.

$$V = \frac{Q \text{ (Lpm)}}{6 \times \pi \times r^2 \text{ (cm)}} = \text{m/s} \qquad V = \frac{Q \text{ (GPM)}}{3.12 \times \pi \times r^2 \text{ (in)}} = \text{ft/s}$$

The size of the air filter should be 3 times greater than the max. instant return flow (all cylinders in movement for example).

If the pump is in the tank, please choose the NOP option (no paint) and use a short inlet pipe.

DENISON does not recommend inlet strainers. If needed, a 100 mesh (149 microns) is the finest mesh recommended.

A coaxial drive is recommended. For any other type of drives, please contact DENISON.

Make sure that all protective plugs & covers have been removed.

Check the pump rotation versus the E-motor or engine rotation.

### Start-up :

The tank has been filled up with a clean fluid in proper conditions.

Flushing the system with an external pump prior to the start-up is good.

To allow a good priming of the pump, the air should be bled off.

The first valve on the circuit should be open to tank.

Air bleed off valves are available on the market place.

It is possible to bleed off the air by creating a leak in the P port of the pump.

**Warning : this has to be done in low pressure mode as it could create a dangerous fluid leak. Make sure that the pressure cannot rise (open center valve to tank, pressure relief valve unloaded ...).**

When oil free of air appears, tighten the connectors to the correct torque.

The pump should prime within a few seconds. If not, please read the troubleshooting guide (page 33).

If the pump is noisy, please troubleshoot the system.

Never operate the pump at top speed and pressure without checking the completion of pump priming.

### **1 . 2 . SHAFT & COUPLING DATA :**

#### **COUPLINGS AND FEMALE SPLINES**

- ◆ The mating female spline should be free to float and find its own center. If both members are rigidly supported, they must be aligned within 0,15 TIR (0.006" TIR) or less to reduce fretting. The angular alignment of two splines axes must be less than  $\pm 0,05$  per 25,4 radius ( $\pm 0.002$ " per 1" radius).
- ◆ The coupling spline must be lubricated with a lithium molydisulfide grease, disulfide of molybdenum or a similar lubricant.
- ◆ The coupling must be hardened to a hardness between 29 and 45 HRC.
- ◆ The female spline must be made to conform to the Class 1 fit as described in SAE-J498b (1971). This is described as a Flat Root Side Fit.

#### **KEYED SHAFTS**

DENISON Hydraulics supplies the T6 series keyed shaft pumps with high strength heat-treated keys. Therefore, when installing or replacing these pumps, the heat-treated keys must be used in order to ensure maximum life in the application. If the key is replaced, it must be a heat-treated key between 27 and 34 R.C. hardness. The corners of the keys must be chamfered by 0,76 mm to 1,02 mm (0.03 to 0.04) at 45° to clear the radii in the key way.

The alignment of keyed shafts must be within tolerances given for splined shafts here above.

#### **SHAFT LOADS**

These products are primarily designed for coaxial drives which do not impose axial or side loading on the shaft. Contact DENISON for specific applications.

### **1 . 3 . SPECIFIC POINTS :**

#### **MINIMUM INLET PRESSURE**

Please read the charts in the sales leaflets as the minimum requested inlet pressure varies versus the displacement and the speed.  
Never go under 0,8 bar Absolute (-0,2 bar relative)  
11.6 PSI Absolute (-2.9 PSI G).

#### **MAXIMUM INLET PRESSURE**

It is recommended to always have at least 1,5 bar (22 PSI) differential between inlet and outlet.  
Standard shaft seals are limited to 0,7 bar (10 PSI G) but some allow 7 bar (100 PSI G). Please contact DENISON for more information.

#### **MINIMUM OUTLET PRESSURE**

It is recommended to always have at least 1,5 bar (22 PSI) differential between inlet and outlet.

#### **VERTICAL MOUNT**

When assembled vertically, always be careful to prevent any air from being trapped in the pump (behind the shaft seal for example).

## 1 . 4 . FLUIDS :

### DENISON CLASSIFICATIONS

Types of fluids : For all types of fluids, DENISON's products have different pressures, speeds & temperature limits. Please refer to the sales leaflets.

HF-0 = Anti-wear petroleum base.  
 HF-1 = Non anti-wear petroleum base.  
 HF-2 = Anti-wear petroleum base.  
 HF-3 = Water-in-oil invert emulsions.  
 HF-4 = Water glycol solutions.  
 HF-5 = Synthetic fluids.

### FILTRATION RECOMMENDATIONS

NAS 1638 class 8 or better.  
 ISO 18 / 14 or better.

Inlet strainers : DENISON does not recommend inlet strainers.  
 If requested, a 100 mesh (149 microns) is the finest mesh recommended.

### RECOMMENDED FLUIDS

Petroleum based antiwear R & O fluids.  
 These fluids are the recommended fluids for pumps & motors. Maximum catalog ratings and performance data are based on operation with these fluids. These fluids are covered by DENISON Hydraulics HF-0 and HF-2 specifications.

### ACCEPTABLE ALTERNATE FLUIDS

The use of fluids other than petroleum based antiwear R & O fluids requires that the maximum ratings of the pumps will be reduced. In some cases the minimum replenishment pressures must be increased. Consult specific sections for more details (page 4).

### VISCOSITY

	Mobile	Industrial
Max. (cold start, low speed & pressure)	2000 cSt - 9400 SUS	860 cSt - 3900 SUS
Max. (full speed & pressure)	108 cSt - 500 SUS	108 cSt - 500 SUS
Optimum (max. life)	30 cSt - 140 SUS	30 cSt - 140 SUS
Min. (full speed & pressure for HF-1, HF-3, HF-4 & HF-5 fluids)	18 cSt - 90 SUS	18 cSt - 90 SUS
Min. (full speed & pressure for HF-0 & HF-2 fluids)	10 cSt - 60 SUS	10 cSt - 60 SUS

### VISCOSITY INDEX

90 min. Higher values extend the range of operating temperatures.

### TEMPERATURES

The usual limiting factor of temperature (low or high) comes from the obtained viscosity. The seals are sometimes the limit : standard seals range from -30° C to 90° C (-9.4° F to 194° F).



	° C	° F
Maximum fluid temperature (θ)		
HF-0, HF-1, HF-2	+ 100	+ 212
HF-3, HF-4	+ 50	+ 122
HF-5	+ 70	+ 158
Biodegradable fluids (esters & rapeseed base)	+ 65	+ 149
Minimum fluid temperature (θ) (also depend on max. viscosity)		
HF-0, HF-1, HF-2, HF-5	- 18	- 0.4
HF-3, HF-4	+ 10	+ 50
Biodegradable fluids (esters & rapeseed base)	- 18	- 0.4

Over or under these values, please contact DENISON.

### WATER CONTAMINATION IN THE FLUID

Maximum acceptable content of water :  
 ♦ 0,10 % for mineral base fluids.  
 ♦ 0,05 % for synthetic fluids, crankcase oils, biodegradable fluids.  
 If the amount of water is higher, then it should be drained off the circuit.


## 2. PUMP & CARTRIDGE BREAKDOWN DRAWING




3.1. COMPLETE DISASSEMBLY OF THE PUMP :

1. Install the pump on the table.

Two bolts will help to unscrew the 4 pump bolts.




2. Unscrew the bolts.




3.1. COMPLETE DISASSEMBLY OF THE PUMP :

3. Remove the end cap (P2 cartridge will come with it).



Cartridge : be careful as some items could fall if the retaining cartridge bolts are totally loose or broken.




The seal usually stays in the rear cap.



3.1. COMPLETE DISASSEMBLY OF THE PUMP :

4 . Disassemble the P2 cartridge / end cap with an extractor.




If you want to continue the pump disassembly (P2 & shaft), go to next page.



If you want to reassemble the P2 cartridge, go to page 17.

5 . Put two screws in the housing and flip the pump (housing + P1 assy).

If you want to convert P2, go to page 13.





3.1. COMPLETE DISASSEMBLY OF THE PUMP :

6. Remove the bolts.



For all pumps except :  
T6EES / T7EES - T6DDS / T7DDS


For pumps :  
T6EES / T7EES - T6DDS / T7DDS



7. Remove the front cap.




P1 cartridge will come with the front cap / shaft assembly.



3.1. COMPLETE DISASSEMBLY OF THE PUMP :


8. Disassemble the P1 cartridge / front cap with an extractor.



If you wish to convert the cartridge, go to page 13.

A: Remove the retaining ring.

B: Extract the shaft / bearing assembly.




Take a protection cone to prevent seal damage (dim. page 30).  
If you don't, change the shaft seal.

If not new, the shaft seal should be replaced.

If the shaft  $\varnothing$  is bigger than the shaft seal  $\varnothing$ , please contact DENISON (TPI).

3.1. COMPLETE DISASSEMBLY OF THE PUMP :

9. Shaft seal out




3.2. CHANGING ROTATION :


1. Explanations :

Bi & uni-rotational port plates.


**Bi-rotational port plate**




**Uni-rotational port plate**



**Bi-rotational port plate**



**Uni-rotational port plate**




#### 3.2. CHANGING ROTATION :




It is possible to change the rotation if the port plates are bi-rotational.

If uni-rotational, change the port plates to change the rotation.

2. Remove the two retaining screws.



3. Remove the rear port plate.




Rear port plate with or without bushing, it depends :


P2 position = no bushing.  
P3 position = with bushing.

3.2. CHANGING ROTATION :

4 . Take the cam ring out, flip it around the horizontal axis.




5 . Change the dowel pin from A to B. Position the cam ring.



3.2. CHANGING ROTATION :

6. Position the dowel pin.

7. Position the port plate & screws.



Before tightening the screws, rotate the rotor/vane.


Retaining screws = assembly purpose & concentricity of the elements.

Rotate rotor after cartridge assembly.

The screws should only be loosely tightened.

**GOOD  
CONCENTRICITY**

**BAD  
CONCENTRICITY**




If the elements are not properly assembled together (bad concentricity), the cartridge will not fit correctly into the housing.




**3.3. COMPLETE REASSEMBLY OF THE PUMP :**

1. Fit the cartridge (P1) into the housing.



2. Check if the dowel pin is in its position in the housing by trying to rotate the cartridge.



If the cartridge does rotate, the dowel pin is not in the hole. Take the cartridge out and try again.


3.3. COMPLETE REASSEMBLY OF THE PUMP :

A : Protective cone on the shaft assembly (dimensions per shaft in page 30).

B : Shaft assembly + protective cone into the front cap. Slightly rotate the shaft to avoid the shaft seal lip(s) to be deteriorated.

C : Retaining ring into the front cap.

3 . Assemble the front cap assy on the housing & cartridge assy.



To avoid damaging the shaft seal do not forget to put a protective cone on the shaft (dim. page 30).



Push on the external bearing "cage".




If the shaft  $\varnothing$  is bigger than the shaft seal  $\varnothing$ , please contact DENISON (TPI)




Position the shaft / front cap assy only if the cartridge is well positioned, dowel pin in the housing dowel pin hole.


Put some grease on the seals to prevent them from moving.



3.3. COMPLETE REASSEMBLY OF THE PUMP :



- a) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.
- b) Check the porting configuration (see table page 28).
- c) Tighten the 4 bolts.



Step by step to avoid damaging the seals.

- d) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.

**TORQUE REQUIREMENTS.**


		Nm	Ft.Lbs
T7BB/S	Housing	187	138
	End cap	61	45
T6CC/M/P – T67CB	Mounting cap	159	117
	End cap	61	45
T7DB/S – T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P	Mounting cap	187	138
	End cap	68	50
T6DD/S - T7DD/S	Housing & end cap	190	140
T6ED/M/P – T7ED/S	Mounting cap & end cap	187	138
T6EE/S - T7EE/S	Cover	88	65
	End cap & Housing	300	221

3.3. COMPLETE REASSEMBLY OF THE PUMP :

4 . Fit the cartridge (P2) into the housing.

5 . Check if the dowel pin is in its position in the housing by trying to rotate the cartridge.

6 . Assemble the end cap on the housing assy.



If the cartridge does rotate, the dowel pin is not in the hole. Take the cartridge out and try again.



Position the shaft / front cap assy only if the cartridge is well positioned, dowel pin in the housing dowel pin hole.




Put some grease on the seals to prevent them from moving.



Always check if the shaft rotates freely. If not, disassemble and go back to the previous step.

3.3. COMPLETE REASSEMBLY OF THE PUMP :

7. Final assy.



- a) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.
- b) Check the porting configuration (see table page 28).
- c) Tighten the 4 or 7 bolts.



Step by step to avoid damaging the seals.

- d) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.

**TORQUE REQUIREMENTS.**

		Nm	Ft.Lbs
<b>T7BB/S</b>	Housing	187	138
	End cap	61	45
<b>T6CC/M/P – T67CB</b>	Mounting cap	159	117
	End cap	61	45
<b>T7DB/S – T6DC/M/P</b> <b>T67DC – T7EB/S</b> <b>T6EC/M/P – T67EC/M/P</b>	Mounting cap	187	138
	End cap	68	50
<b>T6DD/S – T7DD/S</b>	Housing & end cap	190	140
<b>T6ED/M/P – T7ED/S</b>	Mounting cap & end cap	187	138
<b>T6EE/S – T7EE/S</b>	Cover	88	65
	End cap & Housing	300	221

3.4. CHANGING PORTING - P1 :

P1 porting


1. Install the pump on the table.

Two bolts will help unscrew the 4 opposite pump bolts.

2. Unscrew the 4 bolts.




For all pumps except :  
T6EES / T7EES  
T6DDS / T7DDS



Bolts blocking the pump



For pumps :  
T6EES / T7EES  
T6DDS / T7DDS



3.4. CHANGING PORTING - P1 :

P1 porting

3. Flip the pump upside-down.



For all pumps except :  
T6EES / T7EES  
T6DDS / T7DDS




For pumps :  
T6EES / T7EES  
T6DDS / T7DDS


4. Unscrew the 4 bolts.

5. Keep two bolts.

6. Rotate the housing with a bar blocked between the two screws.

 don't lift or move the housing.

Note : the cartridge will rotate with the housing.




3.4. CHANGING PORTING - P1 :

7. Put the screws back.




For all pumps except :  
T6EES / T7EES  
T6DDS / T7DDS

For pumps :  
T6EES / T7EES  
T6DDS / T7DDS



- a) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.
- b) Check the porting configuration (see table page 28).
- c) Tighten the 4 bolts.



Step by step to avoid damaging the seals.

- d) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.

**TORQUE REQUIREMENTS.**

		Nm	Ft.Lbs
<b>T7BB/S</b>	Housing	187	138
	End cap	61	45
<b>T6CC/M/P – T67CB</b>	Mounting cap	159	117
	End cap	61	45
<b>T7DB/S – T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P</b>	Mounting cap	187	138
	End cap	68	50
<b>T6DD/S - T7DD/S</b>	Housing & end cap	190	140
<b>T6ED/M/P – T7ED/S</b>	Mounting cap & end cap	187	138
<b>T6EE/S - T7EE/S</b>	Cover	88	65
	End cap & Housing	300	221



3.5. CHANGING PORTING - P2 :

P2 porting


1. Install the pump on the table.

Insert 2 bolts in the front cap to prevent the pump from moving.




2. Unscrew the 4 or 7 bolts.

3. Keep two bolts.

4. Rotate the end cap with a bar blocked between the two screws.


 don't lift or move the housing.

Note : the cartridge will rotate with the housing.





3.5. CHANGING PORTING - P2 :

5. Put the screws back.



- a) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.
- b) Check the porting configuration (see table page 28).
- c) Tighten the 4 bolts.



Step by step to avoid damaging the seals.

- d) Always check if the shaft rotates freely.  
If not, disassemble and go back to the previous step.

**TORQUE REQUIREMENTS.**

		Nm	Ft.Lbs
<b>T7BB/S</b>	Housing	187	138
	End cap	61	45
<b>T6CC/M/P – T67CB</b>	Mounting cap	159	117
	End cap	61	45
<b>T7DB/S – T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P</b>	Mounting cap	187	138
	End cap	68	50
<b>T6DD/S - T7DD/S</b>	Housing & end cap	190	140
<b>T6ED/M/P – T7ED/S</b>	Mounting cap & end cap	187	138
<b>T6EE/S - T7EE/S</b>	Cover	88	65
	End cap & Housing	300	221

**4 . 1 . PORTINGS :**

**Model No.**

**T67DC W - B42 - 010 - 1 R 00 - A 1 - M1 - ..**

Series - SAE B 2 bolts  
Mounting Flange J744

Severe duty shaft

Displacement for "P1"

Volumetric displacement (ml/rev)

B14 = 44,0      B31 = 99,2  
B17 = 55,0      B35 = 113,4  
B20 = 66,0      B38 = 120,6  
B22 = 70,3      B42 = 137,5  
B24 = 81,1      045 = 145,7  
B28 = 90,0      050 = 158,0

Displacement for "P2"

Volumetric displacement (ml/rev)

003 = 10,8      017 = 58,3  
005 = 17,2      020 = 63,8  
006 = 21,3      022 = 70,3  
008 = 26,4      025 = 79,3  
010 = 34,1      028 = 88,8  
012 = 37,1      031 = 100,0  
014 = 46,0

Type of shaft

1 = keyed (SAE C)      3 = splined (SAE C)  
2 = keyed (non SAE)      4 = splined (spec. SAE C)

Type of shaft - Severe duty (T67DCW only)

5 = keyed (non SAE)

**Modifications**

Mounting w/connection variables  
4 bolts SAE flange J518

	Metric thread		UNC thread	
	M0	M1	00	01
P1	1"1/4	1"1/4	1"1/4	1"1/4
P2	1"	3/4"	1"	3/4"
S	3"	3"	3"	3"

**Seal class**

1 = S1 - BUNA N  
4 = S4 - EPDM  
5 = S5 - VITON

**Design letter**

Porting combination  
00 = standard

**Direction of rotation (view on shaft end)**

R = Clockwise  
L = Counter-clockwise

**4 . 2 . TORQUE REQUIREMENTS.**

		Nm	Ft.Lbs
<b>T7BB/S</b>	Housing	187	138
	End cap	61	45
<b>T6CC/M/P - T67CB</b>	Mounting cap	159	117
	End cap	61	45
<b>T7DB/S - T6DC/M/P</b> <b>T67DC - T7EB/S</b> <b>T6EC/M/P - T67EC/M/P</b>	Mounting cap	187	138
	End cap	68	50
<b>T6DD/S - T7DD/S</b>	Housing & end cap	190	140
<b>T6ED/M/P - T7ED/S</b>	Mounting cap & end cap	187	138
<b>T6EE/S - T7EE/S</b>	Cover	88	65
	End cap & Housing	300	221

4 . 3 . PORTING TABLES :

T7BB/T7BBS

T6CC


T67CB

T7DB/T7DBS

T67DC

T7EB/T7EBS


T67EC



T7DD/T7DDS

T7ED/T7EDS


T7EE/T7EES



## 5. SPECIAL TOOLS

### 5.1. SEAL DRIVER - DIMENSIONS :

Series	Tool N°	Ø A		Ø B		C	
		mm	inch	mm	inch	mm	inch
T67CB - T6CC/M/P	DM3-418S0-1	25,27	0.995	37,82	1.489	145	5.708
		25,40	1.000	37,98	1.495		
T7DB/S - T67DB T6DC/M/P - T67DC	DM3-418S0-2	34,74	1.368	56,92	2.241	145	5.708
		34,90	1.374	57,11	2.248		
T6DDS - T7DD/S T7EB/S - T6EC/M/P - T67EC T6ED/M/P - T7ED/S	DM3-418S0-4	41,11	1.618	59,97	2.361	145	5.708
		41,27	1.625	60,16	2.368		
T6GCC	DM3-418S1-3	44,00	1.732	61,71	2.429	70	2.756
		44,10	1.736	61,90	2.437		
T6EE - T7EE/S	DM3-418S1-6	47,90	1.886	61,75	2.431	145	5.708
		47,95	1.888	61,85	2.435		
T7BB/S	DM3-418S1-0	31,60	1.244	44,16	1.738	145	5.708
		31,75	1.250	44,32	1.745		




#### NOTES :

1. Remove all burrs and break sharp edges: 0.25/0.13 R (.010/.005 R).
2. Length  $\Delta$  to be heat treated to RC 47/50.
3. Length  $\Delta$  to have a  $\sqrt{\text{full length}}$  full length, with a smooth intersection between chamfer and dia. "A".
4. Grease O.D. of length  $\Delta$  before installing the shaft seal on the tool to prevent damaging the seal.  
Material 4140 or equivalent.

### 5.2. PROTECTIVE CONE - DIMENSIONS :

Series	Code N°	Tool N°	A		Ø B		Ø C	
			mm	inch	mm	inch	mm	inch
T6CC	Code 1	DM3-392CP-01	70,0	2.756	25,30 25,40	0.996 1.000	22,28 22,35	0.877 0.880
	Code 2	DM3-392CP-15	70,0	2.756	31,77 31,72	1.251 1.249	25,43 25,51	1.001 1.004
	Code 5	DM3-392CP-33	38,0	1.496	25,30 25,40	0.996 1.000	21,86 21,81	0.859 0.861
T6CCP	Code 3	DM3-392CP-17	36,0	1.417	31,77 31,72	1.251 1.249	21,85 21,93	0.860 0.863
T6CCM	Code 5	DM3-392CP-25	45,0	1.771	25,45	1.002	20,98	0.826
					25,35	0.998	21,05	0.829




#### NOTES :

1. Remove all burrs and break sharp edges: 0.25/0.13 R (.010/.005 R).
2. Teflon preferred, alternate 4140 treated after machining to RC 50-55.
3. Install protective cone over shaft extension and grease O.D. to prevent damaging the shaft seal.

\* full length of O.D. no tool marks or scratches permissible with a smooth intersection between 10° chamfer & dia. "B".

5.2. PROTECTIVE CONE - DIMENSIONS :

Series	Code N°	Tool N°	A		Ø B		Ø C			
			mm	inch	mm	inch	mm	inch		
T7BBS	Code 1	DM3-392CP-05	70,0	2.756	31,77 31,72	1.251 1.249	22,28 22,35	0.877 0.880		
	Code 3	DM3-392CP-17	36,0	1.417	31,77 31,72	1.251 1.249	21,85 21,93	0.860 0.863		
	Code 4	DM3-392CP-41	45,0	1.771	31,77 31,72	1.251 1.249	25,02 25,07	0.985 0.987		
T7BB	Code 5	DM3-392CP-19	68,0	2.677	31,77 31,72	1.251 1.249	25,03 25,13	0.985 0.989		
T67CB	Code 1	DM3-392CP-01	70,0	2.756	25,30 25,40	0.996 1.000	22,28 22,35	0.877 0.880		
	Code 2	DM3-392CP-15	70,0	2.756	31,77 31,72	1.251 1.249	25,43 25,51	1.001 1.004		
	Code 5	DM3-392CP-25	45,0	1.771	25,45 25,35	1.002 0.998	20,98 21,05	0.826 0.829		
T7DB/S T6DC T67DC	Code 1 & 2	DM3-392CP-02	83,0	3.268	34,95 35,00	1.376 1.378	31,80 31,88	1.252 1.255		
	Code 3 Code 4	DM3-392CP-14	60,0	2.362			31,25 31,33	1.230 1.233		
	Code 5	DM3-392CP-16	80,0	3.150	41,25 41,33	1.624 1.627	34,95 35,03	1.376 1.379		
T6DDS T7DD/S	Code 1	DM3-392CP-11	80,0	3.150	41,25 41,33	1.624 1.627	31,80 31,88	1.252 1.255		
	Code 2	DM3-392CP-04	89,0	3.504			38,15 38,23	1.502 1.505		
	Code 3	DM3-392CP-10	55,0	2.165					31,25 31,33	1.230 1.233
	Code 4	DM3-392CP-39	50,0	1.968					25,05 25,13	0.986 0.989
Code 5	DM3-392CP-24	93,0	3.661			34,92 35,00	1.375 1.378			
T7EB/S T6EC T67EC T6ED T7ED/S	Code 1	DM3-392CP-04	89,0	3.504	41,25 41,33	1.624 1.627	38,15 38,23	1.502 1.505		
	Code 2	DM3-392CP-11	80,0	3.150			31,80 31,88	1.252 1.255		
	Code 3	DM3-392CP-10	55,0	2.165					31,25 31,33	1.230 1.233
Code 4	DM3-392CP-12	60,0	2.362			37,60 37,68	1.480 1.483			
T6EE T7EE/S	Code 1	DM3-392CP-37	85,0	3.346	47,95 48,00	1.888 1.890	38,15 38,23	1.502 1.505		
	Code 2	DM3-392CP-26	90,0	3.543			45,03 45,06	1.773 1.774		
	Code 3	DM3-392CP-38	56,0	2.205	39,95 40,00	1.573 1.575	37,60 37,70	1.480 1.484		
	Code 4	DM3-392CP-27	72,0	2.835	47,95 48,00	1.888 1.890	43,72 43,80	1.721 1.724		
Code 5	DM3-392CP-34	96,0	3.779			44,50 44,60	1.752 1.756			



NOTES :


1. Remove all burrs and break sharp edges: 0.25/0.13 R (0.010/.005 R).
2. Teflon preferred, alternate 4140 treated after machining to RC 50-55.
3. Install protective cone over shaft extension and grease O.D. to prevent damaging the shaft seal.

\* full length of O.D. no tool marks or scratches permissible with a smooth intersection between 10° chamfer & dia. "B".

## 6. COUPLINGS


### 6.1. FEMALE COUPLING DIMENSIONS :

#### SPLINED SHAFTS :



Shafts	T7BBS code 3 T67CB code 5 T6CC* code 5		T7BBS code 4 T67CB code 3 T6CC* code 3 T7DD code 4		T7DB code 3 & 4 T67DC code 3 & 4 T6DC* code 3 & 4 T7DD code 3 T7EB code 3 T6EC* code 3 T67EC code 3 T6ED* code 3 T7ED code 3		T7EB code 4 T6EC* code 4 T67EC code 4 T6ED* code 4 T7ED code 4 T6EE* code 3 T7EE code 3		T6EE* code 4 T7EE code 4	
	SAE B		SAE BB		SAE C		SAE CC		SAE D & E	
Number of teeth	13		15		14		17		13	
Pitch	16/32		16/32		12/24		12/24		8/16	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Major dia.	22,221 22,500	0.8748 0.8858	25,400 25,679	1.0000 1.0110	31,750 32,080	1.2500 1.2630	38,100 38,430	1.5000 1.5130	44,450 44,907	1.7500 1.7680
Minor dia.	19,134 19,261	0.7533 0.7583	22,268 22,395	0.8767 0.8817	27,589 27,716	1.0862 1.0912	33,876 34,003	1.3337 1.3387	38,237 38,364	1.5054 1.5104
Pitch dia.	20,638	0.8125	23,812	0.9375	29,634	1.1667	35,984	1.4167	41,275	1.625
Form dia.	21,908	0.8625	25,082	0.9875	31,326	1.2333	37,676	1.4833	43,815	1.7289
Pin dia.	2,743	0.1080	2,743	0.1080	3,658	0.1440	3,658	0.1440	5,486	0.2160
Max. measurement between two pins	16,505 16,589	0.6498 0.6531	19,722 19,807	0.7765 0.7798	24,305 24,407	0.9569 0.9609	30,562 30,648	1.2032 1.2066	32,940 33,055	1.2969 1.3014
Circular space width : Min. effective Max. actual	2,494 2,560	0.0982 0.1008	2,494 2,560	0.0982 0.1008	3,325 3,398	0.1309 0.1338	3,325 3,401	0.1309 0.1339	4,986 5,065	0.1963 0.1994
Radius max.	0,150	0.0059	0,150	0.0059	0,300	0.0118	0,300	0.0118	0,350	0.0138

#### KEYED SHAFTS :



Shafts	T7BB code 1 T67CB code 1 T6CC* code 1		T7BB code 5		T7BB code 2 T67CB code 2 T6CC* code 2	
	mm	inch	mm	inch	mm	inch
Diameter	22,232 22,253	0.8753 0.8761	25,007 25,028	0.9845 0.9854	25,409 25,434	1.0004 1.0013
W	4,792 4,840	0.1887 0.1906	8,040 8,098	0.3165 0.3188	6,390 6,448	0.2516 0.2539
B	24,50 24,83	0.9646 0.9776	28,22 28,55	1.1110 1.1240	28,22 28,55	1.1110 1.1240

Shafts	T7DB code 1 & 2 T6DC* code 1 & 2 T67DC code 1 & 2 T7DD code 1 T7EB code 2 T6EC* code 2 T67EC code 2 T6ED* code 2 T7ED code 2		T7DB code 5 T7DD code 5		T6DC* code 5 T67DC code 5		T7EB code 5 T7ED code 5		T7DD code 2 T7EB code 1 T6EC* code 1 T67EC code 1 T6ED* code 1 T7ED code 1 T6EE* code 1 T7EE code 1		T6EE* code 2 T7EE* code 2		T6EE* code 5 T7EE code 5	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Diameter	31,759 31,784	1.2504 1.2513	32,025 32,050	1.2608 1.2618	34,909 34,934	1.3744 1.3754	38,025 38,050	1.4970 1.4980	38,109 38,134	1.5004 1.5013	45,009 45,034	1.7720 1.7730	44,459 44,484	1.7504 1.7513
W	7,980 8,038	0.3142 0.3165	10,040 10,098	0.3953 0.3976	7,980 8,038	0.3142 0.3165	10,040 10,098	0.3953 0.3976	9,560 9,618	0.3764 0.3787	14,050 14,120	0.5531 0.5559	11,160 11,230	0.4394 0.4421
B	35,27 35,66	1.3886 1.5220	35,27 35,66	1.3886 1.5220	38,42 38,81	1.5131 1.5280	41,30 41,69	1.6260 1.6413	42,36 42,75	1.6677 1.6831	48,50 48,89	1.9094 1.9248	49,30 49,69	1.9409 1.9563

**7 . VANE TROUBLESHOOTING GUIDE :**

<p>1 . No flow, no pressure</p>	<p>a) Is the pump rotating ?</p> <p>b) Is the rotation in the correct direction?</p> <p>c) Is the air bleed-off done?</p> <p>d) How are the inlet conditions?</p> <p>e) Is the Viscosity not too high?</p> <p>f) Is the pump flow not going somewhere else?</p> <p>g) Is the receptor working correctly?</p> <p>h) Is the speed high enough?</p>	<p>a-1) Check if the coupling is rotating. If not, check the rotation of the electric motor. a-2) Check the keys of the pump and E motor shaft. a-3) Check if the shaft is not broken.</p> <p>b-1) Check if the rotation of the pump corresponds to the arrow on the name plate. b-2) Check if the wiring of the electric motor is correct.</p> <p>c-1) Check that no air is still located in the pressure line. Loosen a connector.</p> <p>d-1) Check if the inlet gate valve is not closed. d-2) Check the oil level. d-3) Check if the inlet hose in the tank is under the oil tank level. d-4) Check if an air intake is not disturbing the inlet (missing inlet flange seal, air trapped in suction line as examples). d-5) Check if the pump is not located too high above the oil level. d-6) Check if the tank is not completely sealed. Then the lack of atmospheric pressure will not allow the pump to prime. d-7) Check if all connections and seals are air-tight.</p> <p>e-1) Check if the oil characteristics are not incompatible with the temperature and the pumps requirements. Too high Viscosity will "stick" the vein fluid and enable the pump to suck the oil correctly.</p> <p>f-1) Check the hydraulic circuit and the main sequences. Doing so, you will check if all the valves are set or work properly. f-2) Check if the main relief valve is not set at an extremely low pressure and therefore bringing all the flow back to the tank. f-3) Check if in the directional valves the spools are not sticking in a position that brings the flow back to the tank. f-4) check if the check valve is not mounted "upside down".</p> <p>g-1) Check if the motor does not let all the flow leak internally. g-2) Check if the cylinder inner seals are not ruined.</p> <p>h-1) Check if the minimum speed is reached. Mobile pumps require 400 rpm and industrial pumps require 600 rpm.</p>
<p>2 . Not enough flow (or not the flow required)</p>	<p>a) Are the components OK?</p>	<p>a-1) Check the displacement of the pump. a-2) Check if the speed of the pump is not too low or too high (E motor or thermic engine sized too small so dropping the speed too low...). a-3) Check if the main relief valve is not set at an extremely low pressure and therefore venting some flow back to the tank.</p>



**7 . VANE TROUBLESHOOTING GUIDE :**

2 . Not enough flow (or not the flow required)  
(continuation)

a) Are the components OK?  
(continuation)

a-4) Check if in the directional valves the spools are not sticking in a position that brings part of the flow back to the tank.  
a-5) Check if the hydraulic motor is not leaking internally due to a bad efficiency, low viscosity...  
a-6) Check if the cylinder inner seals are not ruined and therefore allow internal leakage.

b) Is the connection from the tank to the pump correct?

b-1) Check if there is no air intake between the pump and the inlet pipe (bad seals for example).  
b-2) Check if the inlet hose is convenient for the required velocity ( $0,5 < V < 1,9$  m/s).  
b-3) Check if the pump is not too high compared to the oil level or if the pump is not too far from the tank (check the inlet absolute pressure with the catalog values).  
b-4) Check if the gate valve is not semi-open.  
b-5) Check if the inlet strainer is sized correctly (250 m mesh mini.) or not clogged.

c) Is the tank design correct?

c-1) Check if the oil level is correct.  
c-2) Check if the suction pipe is under the oil level during the complete cycle of the machine.  
c-3) Check if the inlet hose fitted in the tank is cut with an angle wider than 45°.  
c-4) Check if this inlet hose is not too close to the tank wall or to the bottom of the tank and therefore limits the "vein flow".  
c-5) Check if the suction hose is not located near the return line and therefore sucking a lot of air coming from these turbulences.  
c-6) Check if baffles are required to allow correct deaeration of the fluid.  
c-7) Check if the air filter is not clogged or undersized (not well dimensioned).  
c-8) Check if the tank is not fully tight, not allowing the atmospheric pressure to apply.

d) Is the oil convenient?

d-1) Check if the oil characteristics are not incompatible with the pumps requirements.  
d-2) Check if the viscosity is not too high, therefore "sticking" some vanes in the rotor or blocking the vein fluid.  
d-3) Check if the high temperature does not destroy the viscosity of the fluid. Doing so, the internal leakage will "consume" the flow.

3 . No pressure

a) Is the hydraulic circuit correctly designed?

a-1) Check the hydraulic circuit schematic.

b) Is the circuit correctly piped?

b-1) Compare the schematic to the piped circuit.

### 7 . VANE TROUBLESHOOTING GUIDE :

3 . No pressure (continuation)	c) Are the components working properly?	c-1) Check the main sequences. Doing so, you will check if all the valves are set or work properly. c-2) Check if the main relief valve is not set at an extremely low pressure and therefore bringing all the flow back to the tank. c-3) Check if in the directional valves the spools are not sticking in a position that brings the flow back to the tank.
4 . Not enough pressure	a) Check as when "no pressure" 3.	
	b) Is the system well dimensioned?	b-1) Check if the flow required is not over the available flow and therefore cannot build-up pressure.
	c) Is there an internal leakage somewhere that maintains a certain pressure?	c-1) Check all the possible faulty components, from the pump to all the receptors and intermediates (high pressure seals, mechanical wear...).
5 . Uncommon noise level	a) Is the noise coming from the pump?	a-1) Check the mechanical link of the pump shaft : alignment, balancing of the coupling or Universal joint, key properly fastened... a-2) Check if the air bleed has been done correctly. a-3) Check if there is no air intake from the tank to the pump (nor through the shaft seal). a-4) Check if the hose strain force does not create this noise. a-5) Check if the oil level is correct. a-6) Check if the oil in the tank is not aerated. a-7) Check if the strainer is not clogged or under-dimensioned. a-8) Check if the inlet pipe is under the oil level. a-9) Check if the air filter is not clogged or too small. a-10) Check if the speed is not incompatible with the catalog values. a-11) Check if the oil is compatible with the catalog recommendations. a-12) Check if the inlet pressure is not higher than the outlet pressure.
	b) Is the noise coming from the surroundings?	b-1) Check the hoses and see if the noise is not coming back to the pump this way. b-2) Check the pressure piping and see if its length damps or amplifies the noise. b-3) Check if the structure of the tank is stiff enough to avoid amplification/resonance. b-4) Check the E motor fan. b-5) Check the balancing of the E motor. b-6) Check the water cooler and its theoretical limits. b-7) Check the filtration unit, its capacity and if the noise does not come from the opened by-pass valve.

7 . VANE TROUBLESHOOTING GUIDE :

6 . Unusual heat level

a) Does the heat appear when the pump is running without pressure?

a-1) Check the oil level and the suction pipe. Is the oil coming to the pump (check the length of the pipe, its internal diameter, all that could influence the inlet pressure)?  
 a-2) Check if the air bleed has been done correctly.  
 a-3) Check if the flow versus the volume of oil in the tank is correct to obtain a good cooling effect.  
 a-4) Check if a cooler is required or, if there is one, if it is well dimensioned.  
 a-5) If there is a cooler, check if it is working (example for water cooler: is the water flow open or sufficient).  
 a-6) Check if the hydraulic circuit is not bringing back the flow directly to the inlet port. Doing so, it would create a very small closed circuit not able to cool down the fluid.  
 a-7) Check the quality of the fluid.  
 a-8) Check the velocity of the fluid.  
 a-9) Check the filtration unit, its capacity and if the heat does not come from the open by-pass valve or if it is under-dimensioned (bigger delta P).

b) Does the heat appear when the pump is running with pressure?

b-1) Check the viscosity.  
 b-2) Check the pressure rating.  
 b-3) Check if the cooler is working correctly or well dimensioned.  
 b-4) Check if the relief valve is not creating this heat because always open.  
 b-5) Check if any other component in the system is not creating this heat due to an internal defect.  
 b-6) Check if there is a big temperature differential between the inlet and the outlet.

7 . Shaft seal leakage

a) Is the seal destroyed?

a-1) Check the alignment and the correct power transmission (non homokinetic movement, high radial force as examples).  
 a-2) Check the inlet pressure and compare it to the catalog values.  
 a-3) Check if the bad suction conditions do not create a vacuum that could even reverse the seal lip.  
 a-4) Check if the external environment is not too dirty and therefore ruining the seal.

b) Is the seal only leaking?

b-1) Check the alignment of the front shaft and check if there is not any radial load.  
 b-2) Check if seal lip has not been cut during a maintenance operation.  
 b-3) Check if the inlet pressure is not over or under the catalog values. This has to be done for the whole cycle because the inlet pressure can vary from time to time.  
 b-4) Check if the seal material has not been modified because of a too warm environment. The seal can vulcanize and stop sealing correctly.  
 b-5) Check the acidity of the oil that can "burn" the seals material. It will therefore destroy the elasticity of the sealing.  
 b-6) Check if the chosen seal (high pressure seal for example) is not too stiff for the use. If the environment requires some elasticity due to a gentle misalignment, a high pressure seal will not be able to follow the movement and therefore leak.