

Force and Load Charts - ROV Oval Bore

For correct cylinder selection at full rod extension, Force "F" should be below the load curve on the appropriate cylinder chart.

LATERAL LOAD OFFSET

