







## Diagnostic Meters and Accessories

| Description   | The Parker<br>Serviceman | The Parker<br>Service<br>Master Easy | The Parker<br>Service<br>Master Plus | Part Number  |
|---|--------------------------|--------------------------------------|--------------------------------------|--|
| The Parker Serviceman<br>Hand-held meter, 2 inputs<br>(Includes SCSN-450 Power Supply)  | •                        |                                      |                                      | SCM-152-2-02   |
| The Parker Service Master Easy<br>Hand-held meter, 4 inputs, up to 1,000,000 data points<br>(Includes SCSN-450 Power Supply)      |                          | •                                    |                                      | SCM-340-2-02   |
| The Parker Service Master Plus<br>Hand-held meter, 26 inputs, up to 1,000,000,000 data points<br>(Includes SCSN-460 Power Supply) |                          |                                      | •                                    | K-SCM-500-01-01-ENG                                      |
| Storage Case - Small  | •                        |                                      |                                      | SCC-150  |
| Storage Case - Medium   | •                        |                                      |                                      | SC-690   |
| Storage Case - Large Roller   |                          |                                      |                                      | SCC-500-ENG  |
| Storage Insert - Holds Extra Sensors<br>Used with SCC-500-ENG Large Roller Case   | •                        |                                      | •                                    | SCC-500-INLET-ENG  |
| Power Supply<br>120 Volt AC   |                          |                                      |                                      | SCSN-450   |
| Power Supply<br>120 Volt AC   |                          |                                      | •                                    | SCSN-460   |
| Connection Cable - Analog<br>Used between meter and sensors (3M length)   | •                        | •                                    | •                                    | SCK-102-03-02  |
| Extension Cable - Analog Used in series with connection cables (5M length)  | •                        | •                                    | •                                    | SCK-102-05-12  |
| Connection Cable - CAN Used between meter and sensors (2M, 5M, 10M lengths)   |                          |                                      | •                                    | SCK-401-02-4F-4M<br>SCK-401-05-4F-4M<br>SCK-401-10-4F-4M |
| Pressure Transducers - Analog Five measurement ranges   | •                        | •                                    | •                                    | See page F-17  |
| Pressure Transducers - CAN Five measurement ranges  |                          |                                      | •                                    | See page F-18  |
| Flow Sensors - Analog Four measurement ranges   | •                        |                                      | •                                    | See page F-19  |
| Flow Sensors - CAN Four measurement ranges  |                          |                                      | •                                    | See page F-20  |
| <b>Temperature Sensor</b> Used with Parker Flow Sensors or SCTA-1/4 Port Adapter (Requires standard connection cable)             | •                        | •                                    | •                                    | SCT-150-04-02  |
| Port Adapter<br>Converts M10X1 to 1/4" male NPT thread  | •                        | •                                    | •                                    | SCTA-1/4   |
| <b>Tachometer</b> To measure rotational speed (0 to 10,000 RPM)   | •                        | •                                    | -                                    | SCRPM-220  |
| Contact Adapter For SCRPM-220 Tachometer  | •                        | •                                    | •                                    | SCRPMA-001   |
| <b>Focus Adapter</b><br>For SCRPM-220 Tachometer  | •                        | •                                    | -                                    | SCRPMA-002   |
| <b>Diagnostic Test Hose Assembly</b> (19" & 32" lengths) Used with PD style Parker Transducers and diagnostic nipples             | •                        | •                                    | •                                    | PDH-19<br>PDH-32   |
| <b>Voltage Adapter</b> Used with auxiliary sensors  |                          |                                      | •                                    | SCMA-VADC-600  |





## Diagnostic Meters and Accessories Software and Data Cables



| Description   | The Parker<br>Serviceman | Sarvica | The Parker<br>Service<br>Master Plus | Part Number         |
|---|--------------------------|---------|--------------------------------------|---------------------|
| The Parker Serviceman<br>Hand-held meter, 2 inputs<br>(Includes SCSN-450 Power Supply)  | •                        |         |                                      | SCM-152-2-02        |
| The Parker Service Master Easy<br>Hand-held meter, 4 inputs, up to 1,000,000 data points<br>(Includes SCSN-450 Power Supply)      |                          | •       |                                      | SCM-340-2-02        |
| The Parker Service Master Plus<br>Hand-held meter, 26 inputs, up to 1,000,000,000 data points<br>(Includes SCSN-460 Power Supply) |                          |         | •                                    | K-SCM-500-01-01-ENG |
| Data Cable and Software To connect the Serviceman meter to a PC   | •                        |         |                                      | SCSW-KIT-152        |
| SensoWin Software For data transfer from any Parker Service Master meter to a PC  |                          | •       | •                                    | Download from web   |
| <b>Data Cable</b> Used between the Parker Service Master Easy meter and a PC  |                          |         |                                      | SCK-315-02-34       |
| <b>Data Cable</b> Used between the Parker Service Master Plus meter and a PC  |                          |         |                                      | SCK-318-02-35       |



