canfield connector

8510 Foxwood Court Youngstown, Ohio 44514 (330) 758-8299 Fax: (330) 758-8912 www.canfieldconnector.com

SANDWICH CRT


CONDENSATION REMOVAL TIMER (CRT)

- General Description

This Canfield Connector miniature timer makes any valve, with the DIN 43650 Form "A"/ISO 4400, EN175301-803:2000 electrical interface, able to operate as a compressed air system condensate removal valve. The unit installs in a modular form between an existing coil and connector. No new wiring is necessary. Retrofits on virtually any installation. It works with the valve brand of your choice. The cycle and on times are easily adjustable and two indicator lights show status.

Dimensional Data

ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE NOTED




DIN 43650 Form "A" / ISO 4400, EN175301-803:2000 male Connector on Front.



Consult factory for available versions listed by Canadian Standards Association for use with certified electrical equipment.

- Technical Data -

- Voltage ranges: 12 to 60 VDC 12 to 240 VAC 50/60 Hz
- Current draw: 1 Amp max. AC
 - 1 Amp max. DC
- Ambient temperature range: -20° to +65°C
- ISO DIN interface: DIN 43650 Form "A" / ISO 4400, EN175301-803:2000
- Transient suppression: AC MOV
 DC Diode



STATUS POWER VALVE VALVE


DIN 43650 Form "A" / ISO 4400, EN175301-803:2000 female Connector on Rear. Timer can be rotated 180°.


Adjust by hand or screwdriver LEDs can be seen from side view.


- Make any valve a condensate removal system
- Environmental protection: dust tight and water resistant
- All solid state; No moving parts to wear
- Indicator lights standard for power and valve status
- Optional 6 ft PVC cable w/grounded plug available
- Manual override switch

Timer Function

Upon application of power to the input terminals, the OFF time is initiated. At the end of the preset CYCLE time, the solenoid is energized and the ON time begins. At the end of the preset ON time, power is removed from the solenoid and a new cycle begins. Cycling continues until power is removed from the input terminals.







www.comoso.com