


Presto Manifold

| MATERIA | ALS OF CONSTRUCTION |
|----------------|---------------------|
| MANIFOLD BODY: | GLASS FILLED NYLON |
| COLLET: | BRASS |
| O-RING: | BUNA N |

| NOMENCLATURE | | | | | |
|------------------|------------------|--|--|--|--|
| EXAMPLE: 24M-6-4 | ATTRIBUTE: | | | | |
| 24M | PRESTO MANIFOLD | | | | |
| 6 | INLET TUBE 6/16 | | | | |
| 4 | OUTLET TUBE 4/16 | | | | |

| SPECIFICATIONS | | | | | | |
|---------------------|----------------|--|--|--|--|--|
| PRESSURE RANGE: | UP TO 150 PSI | | | | | |
| TEMPERATURE RANGES: | -40° TO +200°F | | | | | |

| APPLICABLE TUBE | | | | | |
|-----------------|--|--|--|--|--|
| TUBE MATERIAL: | NYLON, SAE J844 TYPE A & B NYLON TUBING | | | | |
| TUBE O.D.: | 1/4, 3/8, 1/2 | | | | |



The Presto manifold provides a convenient junction to connect multiple tubing lines.

Assembly Instructions

- Cut tubing squarely with Parker tube cutter PTC-001. Be certain that Manifold ports are clean and free of debris.
- Insert tubing into port until it bottoms. Pull on tubing to verify that it is properly retained in the manifold.
- To disassemble, simply hold release button against the manifold body and remove the tubing.
- To reassemble, make certain that the Manifold ports are clean and free of debris and lubricate leading end of the tubing with light oil or petroleum jelly.

Presto Manifold 24M

| PART No. | TUBE O.D. Inlet | TUBE O.D. OUTLET | Α | В | D | G | Н | M | M1 | N |
|-------------|--------------------|---------------------|------|------|-----|------|-----|------|------|------|
| 24M-4-4 | 1/4 | 1/4 | 1.33 | 3.98 | .21 | 2.75 | .53 | .90 | .88 | .89 |
| 24M-6-4 | 3/8 | 1/4 | 1.33 | 4.00 | .21 | 2.75 | .53 | .90 | .88 | .89 |
| 24M-6-6 | 3/8 | 3/8 | 1.65 | 6.49 | .22 | 4.55 | .60 | 1.02 | 1.02 | 1.33 |
| 24M-8-8 | 1/2 | 1/2 | 1.65 | 6.49 | .22 | 4.55 | .60 | 1.02 | 1.02 | 1.33 |
| 24M-8-6446 | 1/2 | 3/8 - 1/4 | 1.65 | 6.49 | .22 | 4.55 | .64 | 1.02 | 1.02 | 1.17 |

